

Service Hints

R10 Rear Fog Light SW

4—Ground : Always approx. 12 volts

1—Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C7	A	40 (LHD)	J2	51 (RHD)	R10
		50 (RHD)	J4	41 (LHD)	R13
C8	B	40 (LHD)		51 (RHD)	53 (RHD)
		50 (RHD)	J12	A	43 (LHD)
C11		40 (LHD)			53 (RHD)
		50 (RHD)	J13	B	51 (RHD)
J2		41 (LHD)	R10		41 (LHD)

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2P		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	60 (LHD)	Instrument Panel Wire and Floor Wire (Left Kick Panel)
	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
II	60 (LHD)	Cowl Side Panel LH
IK	60 (LHD)	Instrument Panel Brace LH
IM	72 (RHD)	Instrument Panel Brace RH
IN	72 (RHD)	Instrument Panel Reinforcement RH
BS	64 (LHD)	Lower Back Panel Center
	76 (RHD)	

○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B7	64 (LHD)	Floor Wire	B7	76 (RHD)	Floor Wire