

Service Hints

I15 Ignition SW

- 2-3 : Closed with the ignition SW at ACC or ON position
- 2-4 : Closed with the ignition SW at ON or ST position
- 2-1 : Closed with the ignition SW at ST position
- 7-6 : Closed with the ignition SW at ON or ST position

TAIL Relay

- 5-3 : Closed with the light control SW at HEAD or TAIL position

HEAD Relay

- 5-3 : Closed with the light control SW at HEAD position or dimmer SW at FLASH position
- Closed with the engine running and parking brake released (Parking brake SW off) (w/ daytime running light)

☐ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A5	36 (LHD 1MZ-FE)	A15	38 (*1)	I15	41 (LHD)
	46 (RHD 1MZ-FE)		46 (RHD 1MZ-FE)		51 (RHD)
A15	36 (LHD 1MZ-FE)		48 (*2)		

* 1 : LHD 2AZ-FE, 1AZ-FE * 2 : RHD 2AZ-FE, 1AZ-FE

☐ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)
2	23	ABS R/B (Radiator Side Support LH)

☐ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
1D		
1E		
1F		
1G		
2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2E	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2F		

☐ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
IF5	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)