

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Seat heaters do not operate	1. SEAT HTR fuse	72-10
	2. Front seat cushion heater assy LH	72-12
	3. Front seat cushion heater assy RH	72-12
	4. Front seatback heater assy LH	72-12
	5. Front seatback heater assy RH	72-12
	6. Seat heater switch	72-12
	7. Wire harness	—