

CUSTOMIZE PARAMETERS

1. BUZZER ON/OFF SETTING

- (a) Check that the ODO display is on, and turn the ignition switch off and then on. If other display is on, change it to the ODO display.
- (b) Within 2 to 6 seconds after turning the ignition switch ON, push the ODO/TRIP switch and hold it for 10 seconds or more.
- (c) Following the table below, set the buzzer ON/OFF setting.

Buzzer	Operation
Seat belt buzzer for driver's seat	Front seat inner belt assy (Driver Side) OFF → ON (Seat belt unfastened → fastened)
Seat belt buzzer for passenger's seat	Sit on the passenger seat and front seat inner belt assy (Passenger Side) OFF → ON (Seat belt unfastened → fastened)

HINT:

The ODO/TRIP display changes from "b-on" to "b-off", entering the cancel mode.

- (d) During the cancel mode, each time the ODO/TRIP switch is pushed, the setting is switched between *1 b-on and *2 b-off.

HINT:

*1 b-on: Cancel is invalid

*2 b-off: Cancel is valid

- (e) After the setting, the mode will be canceled by either not operating the switch for 10 seconds or more, or turning the ignition switch from ON to OFF.

HINT:

The setting can be reset when reconnecting the battery connector or removing/installing the meter connector (Buzzer on).