


BRAKE WARNING LIGHT CIRCUIT

CIRCUIT DESCRIPTION

If the ECU detects trouble, it lights the brake warning light while at the same time prohibiting ABS control. At this time, the ECU records a DTC in memory.

Connect terminals Tc and CG of the DLC3 to make the brake warning light blink and output the DTC.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK PARKING BRAKE SWITCH CIRCUIT

NG

REPAIR OR REPLACE PARKING BRAKE SWITCH CIRCUIT

OK

2 CHECK BRAKE FLUID LEVEL WARNING SWITCH CIRCUIT**NG****REPAIR OR REPLACE BRAKE FLUID LEVEL WARNING SWITCH CIRCUIT****OK****3 RECONFIRM DTC(See page 05-451)**

A

Normal Code

B

Malfunction Code

B**REPAIR CIRCUIT INDICATED BY OUTPUT CODE****A****4 INSPECT COMBINATION METER ASSY (BRAKE WARNING LIGHT CIRCUIT)****NG****REPAIR OR REPLACE COMBINATION METER ASSY****OK****5 CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU ASSY - COMBINATION METER ASSY)(See page 01-31)****NG****REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****CHECK AND REPLACE SKID CONTROL ECU ASSY**