

System Outline

1. Manual Unlock Operation

When the door lock control SW of the driver's side door is pushed to UNLOCK, the door lock will unlock.

2. Manual Lock Operation

When the door lock control SW of the driver's side door is pushed to LOCK, the door lock will lock.

3. Door Key Unlock Operation

* Unlock operation from driver's side door

When the driver's side door is unlocked once using the ignition key, all the other doors are unlocked.

* Unlock operation from front passenger's side door

When the front passenger's side door is unlocked using the ignition key, all the other doors are unlocked.

Service Hints

Body ECU

9-Ground : Approx. 12 volts with ignition SW at ON or ST position

12, 24-Ground : Always continuity

1, 2-Ground : Always approx. 12 volts

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
B5	A	40 (LHD)	D9	42 (LHD)	D15
B7	C	40 (LHD)	D10	42 (LHD)	J7
D6		42 (LHD)	D11	42 (LHD)	J8
D7		42 (LHD)	D12	42 (LHD)	U1
D8		42 (LHD)	D14	42 (LHD)	

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2C		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2H	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2K		
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2R		
2S		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B		

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	60 (LHD)	Front Door LH Wire and Floor Wire (Left Kick Panel)
IB1	60 (LHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IB2		
IC2	60 (LHD)	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IL1	62 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IL2		
IM3	62 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
BA1	64 (LHD)	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	64 (LHD)	Rear Door RH Wire and Floor No.2 Wire (Right Center Pillar)

Door Lock Control (LHD)



: Ground Points

Code	See Page	Ground Points Location
II	60 (LHD)	Cowl Side Panel LH
IJ	60 (LHD)	Instrument Panel Brace LH
BO	64 (LHD)	Under the Driver's Seat
BR	64 (LHD)	Front Side of Rear Quarter Wheel House RH



: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B2	64 (LHD)	Front Door LH Wire			

