

DOOR LOCK CONTROL SYSTEM

1. General

The door lock control system has the following functions:

Function	Outline
Key-linked lock and unlock function* ¹	This function, which is linked with the key cylinder, can lock or unlock all the doors when a lock or unlock operation is effected.
Key confine prevention function	Provided that the key is inserted in the ignition key cylinder and the driver's door is open, an attempt to lock the door will cause all the doors to unlock.
Manual unlock prohibition function	When a lock operation is effected through wireless door lock remote control, this function prohibits the driver's door lock switch from becoming unlocked.
Double Locking System* ²	<ul style="list-style-type: none"> The double locking system also prevents the doors from being opened through the operation of the inside door knobs. Thus, the doors cannot be opened either from the inside or the outside of the vehicle. To lock the doors with this system, pressing the transmitter's LOCK switch, then pressing it again within 5 seconds activates the double locking system. However, as an emergency unlocking maneuver, only the driver's door can be unlocked with a key.

*¹: Except for The European RHD Model

*²: Only for The European RHD Model

CAUTION


This caution is available for the model with double locking system.

Never activate the double locking system when there are people in the vehicle because the doors cannot be opened from the inside of the vehicle.


If locking the doors by accident, press "Unlock" button of the transmitter.

BE

System Diagram



2. Layout of Main Component



208BE58

LHD Model

*: Only for The European RHD Model