

PROBLEM SYMPTOMS TABLE

| Symptom | Suspected Area | See Page |
|---|---|------------------------------|
| Power window does not operate (ALL) (Power Door Lock does not operate) | 1. Power fuse (Instrument Panel J/B) 2. Power main relay (Instrument Panel J/B) 3. Wire harness | 68-1 70-2 — |
| Power window does not operate (ALL) (Power Door Lock is normal) | 1. Ignition switch 2. Power window master switch 3. Wire harness 4. Power window motor | 80-2 05-1154 — 70-2 |
| "One-Touch Power Window System" does not operate | 1. Power window master switch 2. Power window motor (drivers side) | 05-1154 70-2 |
| Only one window glass does not move. | 1. Power window master switch 2. Power window switch 3. Power window motor 4. Wire harness | 05-1154 70-2 70-2 — |
| "Window Lock System" does not operate | 1. Power window master switch 2. Wire harness | 05-1154 — |