



FRONT DIFFERENTIAL ASSY (U140F) OVERHAUL

4006N-01




1. REMOVE FRONT DIFFERENTIAL RING GEAR


- (a) Place the match-marks on the ring gear and differential case.



- (b) Remove the 16 bolts.




- (c) Using a plastic hammer, tap on the ring gear to remove it from the case.




2. REMOVE FRONT DIFFERENTIAL SIDE GEAR


- (a) Remove the differential LH case from the differential case assy.




- (b) Remove the differential case No. 2 from the differential case LH.




- (c) Remove the center differential planetary ring gear, center differential side gear thrust washer No. 2, center differential side gear conical spring washer and differential side gear thrust washer No. 2 RH from the differential case LH.




- (d) Using a snap ring expander, remove the pinion shaft spacer snap ring.




- (e) Using a pin punch and a hammer, remove 3 straight pins.



- (f) Remove the center differential pinion shaft and 2 differential pinion shafts.




- (g) Remove 4 center differential pinions, 4 center differential pinion thrust washers, center differential pinion shaft holder, center differential planetary ring gear and differential side gear thrust washer No. 1.




3. REMOVE FR DIFFERENTIAL CASE REAR TAPERED ROLLER BEARING

- (a) Using SST, remove the front differential case rear tapered roller bearing from the differential case.
SST 09950-00020, 09950-00030, 09950-60010 (09951-00480)



- (b) Using SST, remove the front differential case rear tapered roller bearing outer race and differential case washer.
SST 09308-00010




4. REMOVE CENTER DIFFERENTIAL PINION


- (a) Using torx socket (T50), remove the 15 bolts.




- (b) Place the matchmarks on the differential intermediate case and differential case RH.
(c) Remove the differential intermediate case from the differential case RH.



- (d) Remove the center differential side gear, conical spring washer and center differential side gear thrust washer No. 2 RH from the differential case RH.




- (e) Remove the differential spider, 5 center differential pinions and 5 center differential pinion thrust washers from the differential intermediate case.




5. REMOVE FR DIFFERENTIAL CASE FRONT TAPERED ROLLER BEARING

- (a) Using SST, remove the front differential case front tapered roller bearing from the differential case.
SST 09950-00020, 09950-00030, 09950-60010 (09951-00600)




- (b) Using SST, remove the front differential case front tapered roller bearing outer race and differential case washer.
SST 09308-00010




6. REMOVE TRANSAXLE HOUSING OIL SEAL

- (a) Using SST, remove the oil seal.
SST 09950-70010 (09951-07100), 09649-17010




7. REMOVE DIFFERENTIAL SIDE BEARING RETAINER OIL SEAL

- (a) Using SST, remove the oil seal.
SST 09950-70010 (09951-07100), 09608-10010



8. INSTALL DIFFERENTIAL CASE SUB-ASSY NO.2

- (a) Coat the center differential side gear thrust washer No. 1, center differential planetary ring gear, center differential pinion No. 2, center differential pinion thrust washer No. 2, center differential pinion shaft holder, center differential pinion shaft and 2 differential pinion shafts with ATF, install them to the differential case No. 2.



- (b) Using a dial indicator, measure the backlash of one pinion gear while holding the front differential side gear toward the case.

Standard backlash:

0.05 – 0.20 mm (0.0020 – 0.0079 in.)


NOTICE:

Do not mount the surface of front differential case which contacts with bushing in a vise.


If the backlash is not within the specified value, refer to the table below and select a thrust washer which will ensure that the backlash is within the specified value.

Thrust washer thickness: mm (in.)

Mark	Thickness	Mark	Thickness
A	0.95 (0.0373)	F	1.20 (0.0472)
B	1.00 (0.0393)	G	1.25 (0.0492)
C	1.05 (0.0413)	H	1.30 (0.0512)
D	1.10 (0.0433)	J	1.35 (0.0532)
E	1.15 (0.0453)	K	1.40 (0.0552)



- (c) Engage the front differential side gear to the above mentioned front differential case.
(d) Install the differential case LH to the front differential case and measure its center.
(e) After that, remove the differential case LH.



- (f) Using a straight edge and feeler gauge, measure the clearance between the front differential case and the front differential side gear.

t= Thrust washer thickness

L= Clearance


t= L-0.162 - 0.265 mm (0.0064 - 0.0104 in.)

If the clearance is not within the specified value, refer to the table below and select a thrust washer which will ensure that the clearance is within the specified value.


Thrust washer thickness: mm (in.)

Mark	Thickness	Mark	Thickness
A	0.95 (0.0373)	F	1.20 (0.0472)
B	1.00 (0.0393)	G	1.25 (0.0492)
C	1.05 (0.0413)	H	1.30 (0.0512)
D	1.10 (0.0433)	J	1.35 (0.0532)
E	1.15 (0.0453)	K	1.40 (0.0552)


If the clearance is not within the specified value, parts may have been assembled incorrectly, so check and reassemble it.



- (g) Using a pin punch and a hammer, install 3 straight pins.



- (h) Using a snap ring expander, install the pinion shaft spacer snap ring.




9. INSTALL CTR DIFFERENTIAL PLANETARY GEAR ASSY

- (a) Install the center differential side gear, conical spring washer and center differential side gear thrust washer No. 2 RH from the differential case RH.

HINT:


Ensure that the conical washers is installed correctly.



- (b) Hold the differential case RH by vise. Install the center differential pinion and pinion thrust washer to the differential spider and install them to the differential case RH.

NOTICE:

When holding the differential case RH by vise, be sure to place an aluminum sheet between them and use a minimum force.



- (c) Pressing and holding the differential spider toward the differential case RH, measure the pinion's backlash with a dial indicator as illustrated.


Standard backlash:

0.05 – 0.20 mm (0.0020 – 0.0079 in.)

If the backlash is not within the specified value, refer to the table below and select a thrust washer which will ensure that the backlash is within the specified value.

Thrust washer thickness: mm (in.)


Mark	Thickness	Mark	Thickness
MA	0.80 (0.0313)	MH	1.15 (0.0453)
MB	0.85 (0.0333)	MJ	1.20 (0.0472)
MC	0.90 (0.0353)	MK	1.25 (0.0492)
MD	0.95 (0.0373)	ML	1.30 (0.0512)
ME	1.00 (0.0393)	MM	1.35 (0.0532)
MF	1.05 (0.0413)	MN	1.40 (0.0552)
MG	1.10 (0.0433)	-	-




- (d) Temporarily install the differential side gear thrust washer No. 2 LH, center differential side gear conical spring washer and differential case No.2 to the differential case LH.

HINT:


Ensure that the conical washers is installed correctly.



- (e) Install the differential intermediate case to the above and fix them with 4 bolts.



- (f) Remove the differential spider, 5 center differential pinions and 5 center differential pinion thrust washers from the differential case RH. Put them in the differential intermediate case and fix the case.



- (g) Pressing and holding the differential spider toward the differential intermediate case, measure the pinion's backlash with a dial indicator.


Standard backlash:

0.05 – 0.20 mm (0.0020 – 0.0079 in.)


If the backlash is not within the specified value, refer to the table below and select a thrust washer which will ensure that the backlash is within the specified value.

Thrust washer thickness: mm (in.)


Mark	Thickness	Mark	Thickness
MA	0.80 (0.0313)	MH	1.15 (0.0453)
MB	0.85 (0.0333)	MJ	1.20 (0.0472)
MC	0.90 (0.0353)	MK	1.25 (0.0492)
MD	0.95 (0.0373)	ML	1.30 (0.0512)
ME	1.00 (0.0393)	MM	1.35 (0.0532)
MF	1.05 (0.0413)	MN	1.40 (0.0552)
MG	1.10 (0.0433)	-	-




- (h) Remove the 4 bolts and disconnect the differential case LH from the differential intermediate case.




- (i) Remove the differential case No. 2 from the differential case LH.



- (j) Install the selected differential side gear thrust washer No. 2 LH and center differential planetary gear to the differential case LH.



- (k) Install the differential case No. 2 to the differential case LH again.




- (l) Install the adjusted differential case RH to the intermediate case and tighten the 15 bolts using a torx socket wrench (T50).

Torque: 63 N·m (642 kgf·cm, 46 ft·lbf)

NOTICE:


Align the matchmarks.



10. INSTALL FR DIFFERENTIAL CASE FRONT TAPERED ROLLER BEARING

- (a) Using SST and a press, install the front differential case tapered roller bearing FR to the differential case.

SST 09950-70010 (09951-07100), 09649-17010




- (b) Using SST, install the outer race of the tapered roller bearing FR.

SST 09527-17011, 09950-60020 (09951-01030)

NOTICE:


Clearance is not allowed between the plate washer and transaxle housing.



11. INSTALL FR DIFFERENTIAL CASE REAR TAPERED ROLLER BEARING

- (a) Using SST and a press, install the front differential case tapered roller bearing RR to the differential case.
SST 09316-20011, 09214-76011
- (b) Install the front differential case shim RR to the transaxle case.


If the bearing is new, check to select a front differential case shim RR of proper thickness starting from the thinner ones. If the bearing is reused, check to select a front differential case shim RR starting from the same thickness as one installed before disassembly.



- (c) Using SST, install the outer race of the front differential case tapered roller bearing RR.
SST 09950-60020 (09951-00890), 09950-70010 (09951-07100)


NOTICE:

Clearance is not allowed between the differential case shim and transaxle case.



12. ADJUST TAPERED POLLER BEARING PRELOAD

- (a) Install the intermediate case to the differential case LH and fix them with 4 bolts.
- (b) Install the differential assy to the transaxle case.



- (c) Clean the matching surfaces of the transaxle case and transaxle housing.
- (d) Install the transaxle housing to the transaxle case and tighten them with the 16 bolts.

Torque:

Bolt A: 22.1 N·m (225 kgf·cm, 16.3 ft·lbf)

Bolt B and C: 29.4 N·m (300 kgf·cm, 21.7 ft·lbf)

Bolt length:


Bolt A: 50 mm (1.969 in.)

Bolt B: 50 mm (1.969 in.)

Bolt C: 42 mm (1.654 in.)

HINT:

Usually, bolt A is a non-reusable bolt. In this case, however, it can be used after cleaning it.



- (e) Using SST, turn the differential assy right and left 2 or 3 times to allow the bearing settle.

SST 09564-32011

- (f) Using SST and a torque wrench, measure the turning torque of the differential case assy.

SST 09564-32011

Turning torque at 60 rpm:

New bearing

0.20 – 0.69 N·m (2.0 – 7.0 kgf·cm, 1.8 – 6.1 in.·lbf)

Used bearing


0.10 – 0.35 N·m (1.0 – 3.6 kgf·cm, 0.9 – 3.1 in.·lbf)

HINT:


If the turning torque is not within the specified value, refer to the table below and select a thrust washer which turning torque is within the specified value.

Flange thickness: mm (in.)


Mark	Thickness	Mark	Thickness
0	2.00 (0.0787)	9	2.45 (0.0965)
1	2.05 (0.0807)	A	2.50 (0.0984)
2	2.10 (0.0827)	B	2.55 (0.1004)
3	2.15 (0.0846)	C	2.60 (0.1024)
4	2.20 (0.0866)	D	2.65 (0.1043)
5	2.25 (0.0886)	E	2.70 (0.1063)
6	2.30 (0.0906)	F	2.75 (0.1083)
7	2.35 (0.0925)	G	2.80 (0.1102)
8	2.40 (0.0945)	H	2.85 (0.1122)



- (g) Remove the 16 bolts and the transaxle housing.



- (h) Remove the differential assy.




13. INSTALL FRONT DIFFERENTIAL RING GEAR

- (a) Using ATF and heater, heat the front differential ring gear to 90 - 110 °C. (194.0 - 230.0 °F)

NOTICE:

Do not overheat the ring gear to 110 °C (230.0 °F) or more.


- (b) Clean the contact surface of the front differential case.




- (c) Set the match-marks, install the front differential ring gear case quickly.

NOTICE:

Do not install the bolts while the ring gear is hot.



- (d) Temporarily install the 8 bolts as shown in the illustration.




- (e) Remove the 4 bolts shown in the illustration.
 (f) Temporarily install the remaining 8 set bolts.
 (g) Fully tighten the set bolts.

Torque: 95.1 N·m (970 kgf·cm, 70 ft·lbf)


NOTICE:

Tighten the bolts a little at a time in diagonal order.



14. INSTALL DIFFERENTIAL SIDE BEARING RETAINER OIL SEAL

- (a) Using SST and a hammer, install a new oil seal.
 SST 09223-15020, 09950-70010 (09951-07100)
 (b) Coat the rip of oil seal with a little MP grease.



15. INSTALL TRANSAXLE HOUSING OIL SEAL

- (a) Wind a vinyl tape around SST at the place 6.0 mm (0.236 in.) above from the bottom end until the thickness of the wound tape is about 5.0 mm (0.197 in.).

SST 09950-60020 (09951-00730)

NOTICE:

Remove foreign matter such as grease on the SST before winding the tape.

- (b) Coat the rip of oil seal with a little MP grease.

- (c) Using SST, install a new oil seal.

SST 09950-60020 (09951-00730), 09950-70010 (09951-07150)

Standard press in depth:

5.5 - 6.5 mm (0.217 - 0.256 in.)

NOTICE:

Stop pressing when the wound vinyl tape is contact with the transaxle housing.

