

PARKING BRAKE CABLE ASSY NO.3 REPLACEMENT

3304X-05

HINT:

- COMPONENTS: See page 33-3
- For parking brake cable No.2, employ the same procedure to the RH side.

1. REMOVE REAR WHEEL**2. SEPARATE REAR DISC BRAKE CALIPER ASSY LH**


- (a) Remove the 2 bolts and separate the rear disc brake caliper assy LH.

HINT:

Do not the flexible hose from the brake caliper assy LH.


3. REMOVE REAR BRAKE DRUM SUB-ASSY (DRUM REAR BRAKE TYPE)(See page 32-50)**4. REMOVE REAR DISC (DISC REAR BRAKE TYPE)(See page 33-19)****5. REMOVE PARKING BRAKE SHOE(See page 33-19)****6. REMOVE PARKING BRAKE CABLE HEAT INSULATOR**

- (a) Remove the 3 nuts and parking brake heat insulator.

**7. REMOVE PARKING BRAKE CABLE ASSY NO.3**

- (a) Remove the 2 bolts and disconnect the parking brake cable assy No.3 from the backing plate.

- (b) Remove the 2 nuts, bolt and parking brake cable assy No.3.





- (c) Disconnect the parking brake cable assy No.3 from the parking brake equalizer.

8. INSTALL PARKING BRAKE CABLE ASSY NO.3

- (a) Connect the parking brake cable assy No.3 to the parking brake equalizer.
 (b) Install the parking brake cable assy No.3 with the 2 nuts and bolt.

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)



- (c) Install the parking brake cable assy No.3 with the 2 bolts to the backing plate.

Torque: 7.8 N·m (80 kgf·cm, 69 in·lbf)

9. INSTALL PARKING BRAKE CABLE HEAT INSULATOR

- (a) Install the parking brake heat insulator with the 3 nuts.

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

10. APPLICATION HIGH TEMPERATURE GREASE(See page 33-19)

11. INSTALL PARKING BRAKE SHOE(See page 33-19)

12. **CHECK PARKING BRAKE INSTALLATION**(See page [33-19](#))
13. **INSTALL REAR BRAKE DRUM SUB-ASSY (DRUM REAR BRAKE TYPE)**(See page [32-50](#))
14. **INSTALL REAR DISC (DISC REAR BRAKE TYPE)**(See page [33-19](#))
15. **ADJUST PARKING BRAKE SHOE CLEARANCE**(See page [33-19](#))
16. **INSTALL REAR DISC BRAKE CALIPER ASSY LH**
 - (a) Install the rear disc brake caliper with the 2 bolts.
Torque: 47 N·m (480 kgf·cm, 35 ft·lbf)
17. **INSTALL REAR WHEEL**
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
18. **INSPECT AND ADJUST PARKING BRAKE PEDAL TRAVEL (PEDAL TYPE PARKING BRAKE)**(See page [33-2](#))
19. **INSPECT AND ADJUST PARKING BRAKE LEVER TRAVEL (LEVER TYPE PARKING BRAKE)**(See page [33-2](#))