

CASSETTE TAPE CANNOT BE INSERTED OR PLAYED

INSPECTION PROCEDURE

1 CHECK FOR ANY FOREIGN OBJECT

(a) Check for any foreign objects.

- (1) Check that no foreign objects or defects are detected in the cassette tape player of the radio receiver assembly.

OK: No foreign objects or defects are detected.

NG

REMOVE FOREIGN OBJECT

OK

2 CHECK CASSETTE TAPE

(a) Check the cassette tape.

- (1) Check that the cassette tape is a normal tape with music or voice recorded.

OK: Proper cassette tape with music or voice recorded.

NG

CASSETTE TAPE IS FAULTY

OK

3 REPLACE CASSETTE TAPE WITH ANOTHER AND RECHECK

(a) Replace the cassette tape with another one and recheck.

- (1) Replace the cassette tape with another normal one to see if the same trouble occurs again.

OK: The function returns to be normal.

NG

REPLACE RADIO RECEIVER ASSY
(SEE PAGE 67-4)

OK

CASSETTE TAPE IS FAULTY