


# FRONT DIFFERENTIAL OIL SEAL REPLACEMENT


4104T-06

1. DRAIN MANUAL TRANSAXLE OIL  
Torque: 49 N·m (500 kgf·cm, 36 ft·lbf)
2. REMOVE FRONT WHEELS
3. REMOVE FRONT DRIVE SHAFT ASSY LH (SEE PAGE 30-8)  
SST 09520-01010, 09520-24010 (09520-32040)
4. REMOVE FRONT DRIVE SHAFT ASSY RH (SEE PAGE 30-8)




## 5. REMOVE FRONT TRANSAXLE CASE COVER OIL SEAL

- (a) Using SST, remove the oil seal.  
SST 09308-00010



## 6. REMOVE TRANSMISSION CASE OIL SEAL

- (a) Using SST, remove the oil seal.  
SST 09308-00010




## 7. INSTALL FRONT TRANSAXLE CASE COVER OIL SEAL

- (a) Coat a new oil seal lip with MP grease.
- (b) Using SST and a hammer, install the oil seal.  
SST 09608-10010, 09950-70010 (09951-07200)  
Drive in depth:  $0 \pm 0.5$  mm ( $0 \pm 0.020$  in.)

### NOTICE:

Be careful not to damage the oil seal lip.



## 8. INSTALL TRANSMISSION CASE OIL SEAL

- (a) Coat a new oil seal lip with MP grease.
- (b) Using SST and a hammer, install the oil seal.  
SST 09608-32010, 09950-70010 (09951-07200)  
Drive in depth:  $3.5 \pm 0.5$  mm ( $0.138 \pm 0.020$  in.)

### NOTICE:


Be careful not to damage the oil seal lip.

9. **INSTALL FRONT DRIVE SHAFT ASSY LH (SEE PAGE 30-8)**

10. **INSTALL FRONT DRIVE SHAFT ASSY RH (SEE PAGE 30-8)**

11. **INSTALL FRONT WHEELS**

**Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)**



12. **ADD MANUAL TRANSAXLE OIL**

**Oil grade: API GL-4 or GL-5**

**Viscosity: SAE 75W-90**

**Capacity: 2.5 liters (2.6 US qts, 2.2 Imp. qts)**

**Torque: 49 N·m (500 kgf·cm, 36 ft·lbf)**

13. **INSPECT AND ADJUST MANUAL TRANSAXLE OIL (SEE PAGE 41-2)**

14. **INSPECT AND ADJUST FRONT WHEEL ALIGNMENT (SEE PAGE 26-5)**

15. **CHECK ABS SPEED SENSOR SIGNAL (SEE PAGE 05-933)**