

Service Hints

C4 Cigarette Lighter

- 1—Ground : Approx. 12 volts with ignition SW at ACC or ON position
- 3—Ground : Always continuity

P4 Power Outlet (Front)

- 2—Ground : Approx. 12 volts with ignition SW at ACC or ON position
- 1—Ground : Always continuity

P5 Power Outlet (Rear)

- 2—Ground : Approx. 12 volts with ignition SW at ACC or ON position
- 1—Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C4	40 (LHD)	J4	51 (RHD)	P5	41 (LHD)
	50 (RHD)	P4	41 (LHD)		51 (RHD)
J4	41 (LHD)		51 (RHD)		

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
IK	60 (LHD)	Instrument Panel Brace LH
IM	72 (RHD)	Instrument Panel Brace RH