

System Outline

The cruise control system is a constant vehicle speed controller in which control of the switch on the instrument panel makes it possible to automatically adjust the opening of the engine throttle valve without depressing of the accel. pedal.

1. Set Operation

When the cruise control main SW is turned on, the system starts preparations necessary for the cruise control and turns on the indicator light in the combination meter.

2. Set Speed Control

When the SET/COAST SW is operated with the cruise control main SW turned on during travelling, the constant vehicle speed is controlled.

3. Coast Control

When the SET/COAST SW is kept turned on during cruise control travelling, the engine and ECT ECU (A/T), engine ECU (M/T) controls the throttle valve to decelerate the vehicle. Every time the SET/COAST SW is turned on instantaneously, the vehicle speed is decelerated approximately 1.5 km/h.

4. Accel Control

When the RES/ACC SW is kept turned on during cruise control travelling, the engine and ECT ECU (A/T), engine ECU (M/T) controls the throttle valve to accelerate the vehicle. Every time the RES/ACC SW is turned on instantaneously, the vehicle speed is accelerated approximately 1.5 km/h.

5. Resume Control

When the vehicle speed is within the low speed limit (Approximately 40 km/h, 25 mph) if the cruise control is cancelled, use of the RES/ACC SW accelerates the vehicle to the speed level used before canceling the cruise control.

6. Manual Cancel Mechanism

If any of the following signals is input during cruise control travelling, the cruise control is cancelled.

- * The stop light SW is turned on.
- * The CANCEL SW is turned on.
- * The cruise control main SW is turned off.

7. Auto Cancel Function

If any of the following conditions is encountered, the cruise control is automatically cancelled.

- * The stop light SW wiring is faulty or short-circuited.
- * The vehicle speed signal is faulty.
- * The electronically controlled throttle malfunctions.

8. Overdrive Control Function

The overdrive control may be cancelled if the vehicle travels on the slope during cruise control travelling. After the overdrive control has been cancelled, if the vehicle speed exceeds the overdrive return speed (The set speed is 2 km/h, 1.2 mph) and it is decided that the slope is finished, the vehicle returns to the overdrive control mode again.

Service Hints

E6 (A), E7 (B), E8 (C), E9 (D), E10 (E) Engine and ECT ECU (A/T), Engine ECU (M/T)

- (D) 9—Ground : Approx. 12 volts with ignition SW at ON or ST position
- (D) 3—Ground : Always approx. 12 volts
- (A) 1, (A) 6, (A) 7, (B) 7, (C) 6, (C) 7—Ground : Always continuity
- (E) 19—Ground : Approx. 12 volts with stop light SW at on
- (E) 24—Ground : Continuity with cruise control main SW at on
 - Approx. 1540 Ω with CANCEL SW on in cruise control SW
 - Approx. 240 Ω with RES/ACC SW on in cruise control SW
 - Approx. 630 Ω with SET/COAST SW on in cruise control SW

C10 Combination SW

- 2—3 : Approx. 1540 Ω with CANCEL SW on
- Approx. 240 Ω with RES/ACC SW on
- Approx. 630 Ω with SET/COAST SW on

Cruise Control (2AZ-FE)

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A4	38 (*1)	D3	50 (RHD)	J1	41 (LHD)
	48 (*2)				51 (RHD)
A22	40 (LHD)	E6	A	J7	A
	50 (RHD)				
C7	40 (LHD)	E7	B	J8	B
	50 (RHD)				
C10	40 (LHD)	E8	C	J13	51 (RHD)
	50 (RHD)				41 (LHD)
C12	40 (LHD)	E9	D	S14	51 (RHD)
	50 (RHD)				39 (*1)
D3	40 (LHD)	E10	E	T2	49 (*2)
	40 (LHD)				

* 1 : LHD 2AZ-FE, 1AZ-FE

* 2 : RHD 2AZ-FE, 1AZ-FE

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2L	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M		
2O		
2P		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF2	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
IF4	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
II1	62 (LHD)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	74 (RHD)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IK1	62 (LHD)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	74 (RHD)	
IK2	62 (LHD)	
	74 (RHD)	



: **Ground Points**

Code	See Page	Ground Points Location
ED	58 (*1)	Left Fender
	70 (*2)	
EG	58 (*1)	Left Side of Cylinder Head
	70 (*2)	
EH	58 (*1)	Intake Side of Cylinder Block
	70 (*2)	
II	60 (LHD)	Cowl Side Panel LH
IJ	60 (LHD)	Instrument Panel Brace LH
IK	72 (RHD)	
IN	72 (RHD)	Instrument Panel Reinforcement RH

* 1 : LHD 2AZ-FE, 1AZ-FE

* 2 : RHD 2AZ-FE, 1AZ-FE