

# I GROUND POINT (LHD)

## : Parts Location

Code	See Page	Code	See Page	Code	See Page
J1	41 (LHD)	J4	41 (LHD)		
J2	41 (LHD)	J11	42 (LHD)		

## : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

## : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1J		
1K	25	Engine Wire and Engine Room J/B (Engine Compartment Left)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2D		
2L	29	
2M		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B		

## : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	56 (LHD 1MZ-FE)	Engine Room Main Wire and Engine Room No.2 Wire (Radiator Side Support LH)
	58 (*1)	
EA2	56 (LHD 1MZ-FE)	
IA1	60 (LHD)	Front Door LH Wire and Floor Wire (Left Kick Panel)
IE1	60 (LHD)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)
IF4	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
IF6		
IH1	62 (LHD)	Instrument Panel Wire and Instrument Panel No.3 Wire (Behind the Glove Box)
IK1	62 (LHD)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
IK2		
IL1	62 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BA1	64 (LHD)	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	64 (LHD)	Rear Door RH Wire and Floor No.2 Wire (Right Center Pillar)
BD1	66 (LHD)	Floor Wire and Front Seat LH Wire (Under the Driver's Seat)
BE1	66 (LHD)	Floor No.2 Wire and Front Seat RH Wire (Under the Front Passenger's Seat)

\* 1 : LHD 2AZ-FE, 1AZ-FE


**: Ground Points**

Code	See Page	Ground Points Location
EA	56 (LHD 1MZ-FE)	Right Fender
	58 (*1)	
EB	56 (LHD 1MZ-FE)	
	58 (*1)	
EC	56 (LHD 1MZ-FE)	Left Fender
	58 (*1)	
ED	56 (LHD 1MZ-FE)	
	58 (*1)	
EE	56 (LHD 1MZ-FE)	Surge Tank RH
EF	56 (LHD 1MZ-FE)	Rear Side of Surge Tank
EG	58 (*1)	Left Side of Cylinder Head
EH	58 (*1)	Intake Side of Cylinder Block
II	60 (LHD)	Cowl Side Panel LH
IJ	60 (LHD)	Instrument Panel Brace LH
IK		
IL	60 (LHD)	Instrument Panel Brace RH
IM	60 (LHD)	Instrument Panel Reinforcement RH
IN		
BO	64 (LHD)	Under the Driver's Seat
BP	64 (LHD)	Under the Front Passenger's Seat
BQ	64 (LHD)	Front Side of Rear Quarter Wheel House LH
BR	64 (LHD)	Front Side of Rear Quarter Wheel House RH
BS	64 (LHD)	Lower Back Panel Center
BT	64 (LHD)	Rear Quarter Panel RH

\* 1 : LHD 2AZ-FE, 1AZ-FE


**: Splice Points**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	56 (LHD 1MZ-FE)	Engine Room Main Wire	I8	62 (LHD)	Engine Wire
	58 (*1)		B1	64 (LHD)	Roof Wire
E2	56 (LHD 1MZ-FE)	Engine Room Main Wire	B2	64 (LHD)	Front Door LH Wire
	58 (*1)	Engine Wire	B3	64 (LHD)	Front Door RH Wire
E4	56 (LHD 1MZ-FE)	Engine Wire	B9	64 (LHD)	Floor Wire
E5	58 (*1)		B14	66 (LHD)	Front Seat LH Wire
I6	62 (LHD)		B15	66 (LHD)	Front Seat RH Wire

\* 1 : LHD 2AZ-FE, 1AZ-FE