

## Service Hints

### Body ECU

- 9–Ground : Approx. 12 volts with ignition SW at ON or ST position
- 12, 24–Ground : Always continuity
- 1, 2–Ground : Always approx. 12 volts

### ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
B5	A	D8	52 (RHD)	J5	A
B6	B	D9	52 (RHD)	J6	B
B7	C	D10	52 (RHD)	J7	A
D4	50 (RHD)	D11	52 (RHD)	J8	B
D5	52 (RHD)	D13	52 (RHD)	J11	52 (RHD)
D6	52 (RHD)	D14	52 (RHD)	J13	51 (RHD)
D7	52 (RHD)	D15	52 (RHD)	U1	51 (RHD)

### ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2C		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2H	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2K		
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2P		
2Q		
2R		
2S		
3A	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B		

### □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	72 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IB2		
IC2	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IC3	72 (RHD)	Instrument Panel Wire and Floor MWire (Right Kick Panel)
IL2	74 (RHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IM3	74 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
IM4		
IN1	74 (RHD)	Front Door RH Wire and Floor Wire (Right Kick Panel)
BA1	76 (RHD)	Rear Door LH Wire and Floor No.2 Wire (Left Center Pillar)
BB1	76 (RHD)	Rear Door RH Wire and Floor Wire (Right Center Pillar)

### ▽ : Ground Points

Code	See Page	Ground Points Location
II	72 (RHD)	Instrument Panel Reinforcement LH
IK	72 (RHD)	Instrument Panel Brace LH
IN	72 (RHD)	Instrument Panel Reinforcement RH
BO	76 (RHD)	Under the Front Passenger's Seat
BP	76 (RHD)	Under the Driver's Seat
BQ	76 (RHD)	Front Side of Rear Quarter Wheel House LH
BR	76 (RHD)	Front Side of Rear Quarter Wheel House RH

## Double Locking (RHD)

---



: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B2	76 (RHD)	Front Door LH Wire	B13	76 (RHD)	Rear Door RH Wire
B3	76 (RHD)	Front Door RH Wire	B16	76 (RHD)	Floor Wire
B12	76 (RHD)	Rear Door LH Wire			

