

Service Hints

H4 Headlight Cleaner Relay

- 1—Ground : Approx. 12 volts with ignition SW at ON or ST position
- 5—Ground : Always approx. 12 volts
- 3—Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C11	40 (LHD)	H4	36 (LHD 1MZ-FE)	J4	41 (LHD)
H3	36 (LHD 1MZ-FE)		38 (*1)	J12	41 (LHD)
	38 (*1)	H15	41 (LHD)		

* 1 : LHD 2AZ-FE, 1AZ-FE

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2F	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF6	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)

▽ : Ground Points

Code	See Page	Ground Points Location
EB	56 (LHD 1MZ-FE)	Right Fender
	58 (*1)	
IK	60 (LHD)	Instrument Panel Brace LH

* 1 : LHD 2AZ-FE, 1AZ-FE

○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	56 (LHD 1MZ-FE)	Engine Room Main Wire	E1	58 (*1)	Engine Room Main Wire

* 1 : LHD 2AZ-FE, 1AZ-FE