

<b>DTC</b>	<b>C1223/43</b>	<b>ABS CONTROL SYSTEM MALFUNCTION</b>
------------	-----------------	---------------------------------------

**HINT:**

When DTC C1223/43 is memorized, there is no malfunction in the VSC system.

**CIRCUIT DESCRIPTION**

DTC No.	DTC Detecting Condition	Trouble Area
C1223/43	Malfunction in ABS control system	ABS control system

**INSPECTION PROCEDURE**

<b>1</b>	<b>CHECK DTC</b>
----------	------------------

- (a) Clear the DTCs (see page [05-1002](#)).
- (b) Turn the ignition switch to the ON position.
- (c) Are the DTCs of the ABS system recorded? (see page [05-1002](#))

**NO****REPLACE BRAKE ACTUATOR ASSY  
(SEE PAGE [32-63](#))****YES****REPAIR CIRCUIT INDICATED BY OUTPUT DTC (SEE PAGE [05-1010](#))**