


# FRONT DIFFERENTIAL OIL SEAL (U241E)

400GB-01


## REPLACEMENT

1. REMOVE FRONT WHEEL
2. REMOVE ENGINE UNDER COVER RH
3. REMOVE ENGINE UNDER COVER LH
4. DRAIN AUTOMATIC TRANSAXLE FLUID
  - (a) Remove the drain plug and gasket, and drain ATF.
  - (b) Install a new gasket and drain plug.  
Torque: **49 N·m (500 kgf·cm, 36 ft·lb)**
5. REMOVE FRONT DRIVE SHAFT ASSY RH  
(See page 30-8)
6. REMOVE FRONT DRIVE SHAFT ASSY LH  
(See page 30-8)




### 7. REMOVE TRANSAXLE HOUSING OIL SEAL

- (a) Using SST, pull out the oil seal.  
SST 09308-00010




### 8. REMOVE DIFFERENTIAL SIDE BEARING RETAINER OIL SEAL

- (a) Using SST, pull out the oil seal.  
SST 09308-00010



### 9. INSTALL TRANSAXLE HOUSING OIL SEAL

- (a) Using SST and a hammer, drive in a new oil seal.  
SST 09316-60011 (09316-00011)  
**Oil seal drive in depth:**  
**0 ± 0.5 mm (0 ± 0.020 in.)**
- (b) Coat the lip of the oil seal with MP grease.



# 10. INSTALL DIFFERENTIAL SIDE BEARING RETAINER OIL SEAL

- (a) Using SST and a hammer, drive in a new oil seal.  
SST 09649-17010, 09950-70010 (09951-7150)

**Oil seal drive in depth:**

**$0 \pm 0.5 \text{ mm}$  ( $0 \pm 0.020 \text{ in.}$ )**

- (b) Coat the tip of the oil seal with MP grease.

## 11. INSTALL FRONT DRIVE SHAFT ASSY LH

(See page 30-8)

## 12. INSTALL FRONT DRIVE SHAFT ASSY RH

(See page 30-8)

## 13. INSTALL ENGINE UNDER COVER LH

## 14. INSTALL ENGINE UNDER COVER RH

## 15. INSTALL FRONT WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

## 16. ADD AUTOMATIC TRANSAXLE FLUID

## 17. INSPECT AUTOMATIC TRANSAXLE FLUID (See page 40-1)

## 18. CHECK ABS SPEED SENSOR SIGNAL (See page 05-451 or 05-511)