

TRANSAXLE

■ MANUAL TRANSAXLE

- The E354 manual transaxle is used to improve torque and to achieve a compact and lightweight package.

Engine Type		2AZ-FE
Transaxle Type		E354
Gear Ratio	1st	3.538
	2nd	2.045
	3rd	1.333
	4th	1.028
	5th	0.820
	Reverse	3.583

■ AUTOMATIC TRANSAXLE

- The U241E and U140E automatic transaxles are used.

Engine Type		1AZ-FE 2AZ-FE	1MZ-FE
Transaxle Type		U241E	U140E
Gear Ratio	1st	3.943	3.938
	2nd	2.197	2.194
	3rd	1.413	1.411
	4th	1.020	1.019
	Reverse	3.145	3.141