



**DTC****P1651/96****VSV for ACIS Circuit Malfunction****CIRCUIT DESCRIPTION**

This circuit opens and closes the Intake Air Control Valve in response to the engine load in order to increase the intake efficiency (ACIS: Acoustic Control Induction System).


When the engine speed is 3,700 rpm or less and the throttle valve opening angle is 30° or more, the ECM turns the two VSV ON or OFF and operates the Intake Air Control Valve.

**WIRING DIAGRAM**

## INSPECTION PROCEDURE

## When Using Hand-held Tester:

## 1 PERFORM ACTIVE TEST BY HAND-HELD TESTER (VSV FOR ACIS)



- (a) Turn the ignition switch ON and hand-held tester main switch ON.
- (b) Select the INTAKE CTRL VSV from the ACTIVE TEST menu on the hand-held tester.
- (c) Check the operation of the VSV when the VSV is operated by the hand-held tester.

**VSV is ON:**

Air from port E flows out through port F.

**VSV is OFF:**

Air from port E flows out through the air filter.

OK

INSPECT VACUUM TANK

NG

## 2 CHECK VSV (FOR ACIS) (See Page 13-2)

NG

REPLACE VACUUM SWITCHING VALVE ASSY NO.1

OK


## 3 CHECK HARNESS AND CONNECTOR (E.F.I. ECU RELAY - ECM)

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

CHECK AND REPLACE ECM

**When not using Hand-held Tester:****1 CHECK VSV (FOR ACIS) (See Page 13-2)****NG****REPLACE VACUUM SWITCHING VALVE ASSY NO.1****OK****2 INSPECT ECM**

- (a) Turn the Ignition switch ON.  
 (b) Measure the voltage between terminals ACIS and E2 of the ECM connector.  
**Voltage: 9 - 14 V**

**NG****CHECK HARNESS AND CONNECTOR****OK****3 INSPECT VACUUM TANK (See Page 13-2)****NG****REPAIR OR REPLACE****OK****CHECK AND REPLACE ECM**