

PROBLEM SYMPTOMS TABLE

1. HEADLIGHT AND TAILLIGHT

Symptom	Suspect Area	See page
Only one headlight comes on.	1. Bulb 2. HEAD LH fuse (LWR, UPR) 3. HEAD RH fuse (LWR, UPR) 4. Wire harness	– – – –
Headlight does not light up. (LO-Beam)	–	05-1811
"HI-Beam" does not light (All).	1. Headlight dimmer switch 2. DRL relay 3. Wire harness	65-3 65-3 –
"HI-Beam" does not light (One side).	1. Bulb 2. Wire harness	– –
"Flash" does not light.	1. Headlight Dimmer Switch 2. DRL relay 3. Wire harness	65-3 65-3 –
Headlight is dark.	1. Bulb 2. Wire harness	– –
Only one tail light light up.	1. Bulb 2. Wire harness	– –
Taillight does not light up. (Headlight is normal)	–	05-1813
Taillight does not light up. (Headlight does not light)	1. Light Control Switch 2. Wire harness	65-3 –
Rear combination light does not light up.	1. Bulb 2. Wire harness	– –
Headlight does not light up with engine running and light control switch is in OFF	1. HEAD relay 2. DRL relay 3. Generator L terminal 4. Parking brake switch 5. Multiplex network body computer 6. Wire harness	65-3 65-3 – – 05-1795 –

2. AUTOMATIC LIGHT CONTROL SYSTEM

Symptom	Suspect Area	See page
Automatic light control system does not operate	–	05-1815

3. LIGHT AUTO CUT SYSTEM

Symptom	Suspect Area	See page
Light auto turn off system does not operate.	–	05-1818
Headlight and taillight do not come on.	1. Multiplex network body computer 2. Wire harness	05-1795 –
Headlight and taillight stay on.	1. Multiplex network body computer 2. Wire harness	05-1795 –

4. FOG LIGHT SYSTEM

Symptom	Suspect Area	See page
Front fog light does not light up with light control SW HEAD (Headlight is normal.)	1. FOG Fuse 2. FOG relay 3. Fog light switch 4. Wire harness	– 65-3 65-3 –
Only one front fog light does not light up.	1. Bulb 2. Wire harness	– –

5. TURN SIGNAL AND HAZARD WARNING SYSTEM

Symptom	Suspect Area	See page
"Hazard" and "Turn" do not light up.	1. IG1 Fuse 2. Ignition switch 3. Turn signal flasher 4. Wire harness	– – 65-2 –
Hazard warning light does not light up. (Turn is normal)	1. Hazard warning switch (A/C amplifier) 2. Wire harness	65-3 –
Turn signal does not light up. (Hazard is normal)	1. Turn signal switch 2. Wire harness	65-3 –
Turn signal does not light up in one direction.	1. Turn signal switch 2. Wire harness	65-3 –
Only one bulb does not light up.	1. Bulb 2. Wire harness	– –

6. ILLUMINATED ENTRY SYSTEM

Symptom	Suspect Area	See page
Room lamp assy No.1 does not light up.	–	05-1802
Room lamp assy No.1 does not go off.	–	05-1806