


























DRIVE SHAFT / PROPELLER SHAFT

PREPARATION






020U4-01

SST

	09240-00020	Wire Gauge Set	FRONT DRIVE SHAFT
	09520-00031	Rear Axle Shaft Puller	FRONT AXLE HUB SUB-ASSY LH
	09520-01010	Drive Shaft Remover Attachment	FRONT DRIVE SHAFT
	09520-24010	Differential Side Gear Shaft Puller	FRONT DRIVE SHAFT
	(09520-32040)	Shocker Set	FRONT DRIVE SHAFT
	09521-24010	Rear Axle Shaft Puller	FRONT DRIVE SHAFT
	09527-10011	Rear Axle Shaft Bearing Remover	FRONT DRIVE SHAFT
	09527-17011	Rear Axle Shaft Bearing Remover	FRONT AXLE HUB SUB-ASSY LH
	09527-30010	Rear Axle Shaft Bearing Remover	FRONT DRIVE SHAFT
	09608-16042	Front Hub Bearing Adjusting Tool	FRONT DRIVE SHAFT
	(09608-02021)	Bolt & Nut	FRONT DRIVE SHAFT
	(09608-02041)	Retainer	FRONT DRIVE SHAFT

	09608-32010	Steering Knuckle Oil Seal Replacer	FRONT AXLE HUB SUB-ASSY LH
	09628-10011	Ball Joint Puller	FRONT AXLE LH HUB BOLT REAR AXLE LH HUB BOLT
	09628-62011	Ball Joint Puller	FRONT AXLE HUB SUB-ASSY LH FRONT DRIVE SHAFT
	09726-40010	Lower Control Shaft Bearing Replacer	FRONT DRIVE SHAFT
	09930-00010	Drive Shaft Nut Chisel	FRONT AXLE HUB SUB-ASSY LH FRONT DRIVE SHAFT
	09950-00020	Bearing Remover	FRONT AXLE HUB SUB-ASSY LH FRONT DRIVE SHAFT
	09950-60010	Replacer Set	FRONT AXLE HUB SUB-ASSY LH
	(09951-00410)	Replacer 41	FRONT AXLE HUB SUB-ASSY LH
	(09951-00600)	Replacer 60	FRONT AXLE HUB SUB-ASSY LH
	09950-60020	Replacer Set No.2	FRONT AXLE HUB SUB-ASSY LH
	(09951-00790)	Replacer 79	FRONT AXLE HUB SUB-ASSY LH
	09950-70010	Handle Set	FRONT AXLE HUB SUB-ASSY LH
	(09951-07100)	Handle 100	FRONT AXLE HUB SUB-ASSY LH

Recommended Tools

	09011-12301	Socket Wrench 30 mm	FRONT AXLE HUB SUB-ASSY LH FRONT DRIVE SHAFT
	09040-00011	Hexagon Wrench Set	FRONT DRIVE SHAFT
	(09043-20060)	Socket Hexagon Wrench 6	FRONT DRIVE SHAFT
	09905-00012	Snap Ring No.1 Expander	FRONT DRIVE SHAFT
	09905-00013	Snap Ring Pliers	FRONT AXLE HUB SUB-ASSY LH

Equipment

Torque wrench	
Dial indicator with magnetic base	
Alignment tester	
Toe-in gauge	
Angle gauge	

Lubricant

Item	Capacity
Front drive shaft	
1MZ-FE	Outboard joint grease 205 - 215 g (7.2 - 7.6 oz.)
1AZ-FE/2AZ-FE	Outboard joint grease 190 - 200 g (6.7 - 7.1 oz.)
	Inboard joint grease 185 - 195 g (6.5 - 6.9 oz.)