


DTC	22	COMPRESSOR LOCK SENSOR CIRCUIT
------------	-----------	---------------------------------------

CIRCUIT DESCRIPTION

This sensor sends 4 pulses per engine revolution to the A/C amplifier. If the number ratio of the compressor revolution divided by the engine revolution is smaller than a predetermined value, the A/C amplifier turns the compressor off. And, the indicator flashes at about 1 sec. intervals.


DTC No.	Detection Item	Trouble Area
22	<p>All conditions below are detected for 3 sec. or more.</p> <p>(a) Engine speed : 450 rpm or more.</p> <p>(b) Ratio between engine and compressor revolution deviates 20% or more in comparison to normal operation.</p>	<ul style="list-style-type: none"> • Compressor • Compressor drive belt • A/C lock sensor • Harness or connector between compressor and A/C amplifier • A/C amplifier • ECM (1MZ-FE)

WIRING DIAGRAM



INSPECTION PROCEDURE


1 INSPECT HEATER CONTROL HOUSING SUB-ASSY(A/C)

1MZ-FE: A/C Control Assembly
Connector Wire Harness View:

- (a) Remove A/C amplifier assy with connectors still connected.
- (b) Turn the ignition switch to the ON position.
- (c) 1MZ-FE:
Measure voltage according to the value(s) in the table below.

Standard:

Terminal No.	Condition	Specified Condition
A13-38 (A/C) – Body ground	Ignition switch ON Magnet clutch ON	Below 1.0 V

2AZ-FE: A/C Control Assembly
Connector Wire Harness View:


- (d) 2AZ-FE:
Measure voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A40-4 (LOCK) – Body ground	Ignition switch ON Magnet clutch ON	Pulse generation (see waveform)


Result:

A	NG
B	OK (Checking from DTC)
C	OK (When checking from the PROBLEM SYMPTOMS TABLE)

Waveform:**B****CHECK AND REPLACE HEATER CONTROL HOUSING SUB-ASSY****C****PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE****A**

2 INSPECT COOLER COMPRESSOR ASSY

A/C Look Sensor Connector
Front View:



le-3-2


E05280

- (a) Disconnect compressor connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Terminal No.	Condition	Specified Condition
A3-1 – A3-2	at 20°C (68°F)	165 to 205 Ω



NG**REPLACE COOLER COMPRESSOR ASSY
(SEE PAGE 55-61 or 55-68)****OK****3 CONFIRM MODEL****Result:****A: 1MZ-FE****B: 2AZ-FE****B****Go to step 8****A****4 CHECK HARNESS AND CONNECTOR(COOLER COMPRESSOR ASSY – ECM)****NG****REPAIR OR REPLACE HARNESS OR
CONNECTOR****OK**

5 INSPECT ECM(LCKI)**ECM Wire Harness View:**

- Remove ECM with connector.
- Turn ignition switch ON.
- A/C switch ON.
- Measure waveform between terminal LCKI of ECM and body ground.

Standard : Pulse generation**HINT:**

The correct waveform is as shown.

**NG****REPLACE ECM****OK****6 INSPECT ECM(ACLD)****ECM Wire Harness View:**

- Remove ECM with connector.
- Turn ignition switch ON.
- A/C switch ON.
- Measure voltage according to the value(s) in the table below.

Standard:

Terminal No.	Condition	Specified Condition
E7-33 (ACLD) - Body ground	Magnet clutch OFF	10 to 14 V
E7-33 (ACLD) - Body ground	Magnet clutch ON	Below 1.0 V

NG**REPLACE ECM****OK**

7	CHECK HARNESS AND CONNECTOR(ECM – HEATER CONTROL HOUSING SUB-ASSY)
---	--

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

8	CHECK HARNESS AND CONNECTOR(COOLER COMPRESSOR ASSY – HEATER CONTROL HOUSING SUB-ASSY)
---	---

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE HEATER CONTROL HOUSING SUB-ASSY
