

Service Hints

S3, S4 Seat Heater SW LH, RH

3—Ground : Approx. 12 volts with ignition SW at ON or ST position

6—Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
J4	41 (LHD)	S4	41 (LHD)	S18	44 (LHD)
	51 (RHD)		51 (RHD)		54 (RHD)
S3	41 (LHD)	S17	44 (LHD)		
	51 (RHD)		54 (RHD)		

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	60 (LHD)	Instrument Panel Wire and Floor Wire (Left Kick Panel)
	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IM3	62 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
	74 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
BD1	66 (LHD)	Floor Wire and Front Seat LH Wire (Under the Driver's Seat)
	78 (RHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Front Passenger's Seat)
BE1	66 (LHD)	Floor No.2 Wire and Front Seat RH Wire (Under the Front Passenger's Seat)
	78 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

▽ : Ground Points

Code	See Page	Ground Points Location
IK	60 (LHD)	Instrument Panel Brace LH
IM	72 (RHD)	Instrument Panel Brace RH
BO	64 (LHD)	Under the Driver's Seat
	76 (RHD)	Under the Front Passenger's Seat
BP	64 (LHD)	Under the Front Passenger's Seat
	76 (RHD)	Under the Driver's Seat