

DTC	B0126/27	SEAT BELT BUCKLE SWITCH (LH) MALFUNCTION
------------	-----------------	---

DTC	B0127/27	SEAT BELT BUCKLE SWITCH (LH) MALFUNCTION
------------	-----------------	---

CIRCUIT DESCRIPTION

The seat belt buckle switch (LH) circuit consists of the airbag sensor assy center and front seat inner belt assy (LH).

DTC B0126/B0127/27 is recorded when a malfunction is detected in the seat belt buckle switch (LH) circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B0126/B0127/27	<ul style="list-style-type: none"> • Short circuit in LBE+ wire harness (to ground) • Short circuit in LBE+ wire harness (to B+) • Open circuit in LBE+ wire harness • Front seat inner belt assy (LH) malfunction • Airbag sensor assy center malfunction 	<ul style="list-style-type: none"> • Front seat inner belt assy (LH) • Airbag sensor assy center • Wire harness

WIRING DIAGRAM


LHD:

Seat Belt Buckle Switch (LH)


Airbag Sensor Assy Center



H41704


INSPECTION PROCEDURE**1 CHECK WIRE HARNESS(AIRBAG SENSOR ASSY CENTER - FRONT SEAT INNER BELT ASSY LH)**

- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Disconnect the connector between the airbag sensor assy center and the front seat inner belt assy (LH).
- For the connector (on the airbag sensor assy center side) between the airbag sensor assy center and the front seat inner belt assy (LH), measure the resistance between LBE+ and body ground.


OK:**Resistance: 1 MΩ or Higher****NG****REPAIR OR REPLACE WIRE HARNESS****OK****2 CHECK WIRE HARNESS(AIRBAG SENSOR ASSY CENTER - FRONT SEAT INNER BELT ASSY LH)**

- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the ignition switch to ON.
- For the connector (on the airbag sensor assy center side) between the airbag sensor assy center and the front seat inner belt assy (LH), measure the voltage between LBE+ and body ground.

OK:**Voltage: Below 1 V****NG****REPAIR OR REPLACE WIRE HARNESS****OK**

3 CHECK FRONT SEAT INNER BELT ASSY LH

- (a) Turn the ignition switch to LOCK.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- (c) Connect the connector of the front seat inner belt assy (LH).
- (d) Unlock the seat belt for the front seat LH.
- (e) For the connector (on the airbag sensor assy center side), measure the resistance between LBE+ and body ground.


OK:**Resistance: 1.0 k Ω - 1.6 k Ω** **NG****REPLACE FRONT SEAT INNER BELT ASSY LH****OK****4 CHECK FRONT SEAT INNER BELT ASSY LH**

- (a) Lock the seat belt for the front seat LH.
- (b) For the connector (on the airbag sensor assy center side), measure the resistance between LBE+ and body ground.

OK:**Resistance: 100 Ω - 500 Ω** **NG****REPLACE FRONT SEAT INNER BELT ASSY LH****OK**

5 CHECK AIR BAG SENSOR ASSY CENTER

SST 09843-18040



- Connect the connector to the airbag sensor Assy center.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See page 05-758).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Check the DTC (See page 05-758).

OK:**DTC B0126/B0127/27 is not output.****HINT:**

Codes other than code B0126/B0127/27 may be output at this time, but they are not relevant to this check.

NG**REPLACE AIR BAG SENSOR ASSY CENTER****OK****USE SIMULATION METHOD TO CHECK**