


## REPLACEMENT

1. WORK FOR PREVENTING GASOLINE FROM SPILLING OUT (See page 11-49)
2. DRAIN COOLANT (See page 16-31)
3. REMOVE V-BANK COVER SUB-ASSY (See page 14-156)
4. REMOVE BATTERY
5. REMOVE AIR CLEANER ASSEMBLY WITH HOSE (See page 10-18)
6. REMOVE FRONT SUSPENSION UPPER BRACE CENTER (W/ FRONT SUSPENSION BRACE UPPER CENTER)
7. REMOVE INTAKE AIR SURGE TANK (See page 14-143)




### 8. SEPARATE FUEL PIPE SUB-ASSY NO.1

- (a) Remove the pulsation damper and 2 gaskets.
- (b) Remove the bolt and 2 gaskets.
- (c) Remove the bolt and disconnect the fuel pipe sub-assembly No. 1 from the intake manifold.

### 9. REMOVE FUEL INJECTOR ASSY

- (a) Disconnect the injector connectors.
- (b) Remove the 2 bolts and fuel delivery pipe, while pulling out both ends of the fuel delivery pipe equally.
- (c) While turning the injector clockwise and counterclockwise, pull out the injector from the delivery pipe.



### 10. INSTALL FUEL INJECTOR ASSY

- (a) Apply a light coat of gasoline to a new O-ring and install them to each injectors.
- (b) While turning the injector clockwise and counterclockwise, install it to the delivery pipe.
- (c) Check that the injectors rotate smoothly.

#### NOTICE:


If injectors do not rotate smoothly, the probable cause is incorrect installation of the O-rings. Replace new O-rings.

- (d) Install the delivery pipe with the injectors.

Torque: 10 N·m (102 kgf·cm, 7 ft·lbf)

#### NOTICE:

- Be careful not to drop the injectors when installing the delivery pipe.
- Check that the injectors rotate smoothly after installing the delivery pipe.

**11. INSTALL FUEL PIPE SUB-ASSY NO.1**

- (a) Install the fuel pipe No. 1 with the 2 new pulsation damper gaskets and the pulsation damper.  
**Torque: 33 N·m (336 kgf·cm, 24 ft·lbf)**
- (b) Install the delivery pipe with 2 new fuel pipe No. 1 gaskets and a bolt to the fuel pipe No. 1.  
**Torque: 33 N·m (336 kgf·cm, 24 ft·lbf)**
- (c) Install the fuel pipe No. 1 to the intake manifold with a bolt.  
**Torque: 20 N·m (199 kgf·cm, 14 ft·lbf)**

**12. INSTALL INTAKE AIR SURGE TANK****(See page 14-143)****13. INSTALL FRONT SUSPENSION UPPER BRACE CENTER (W/ FRONT SUSPENSION BRACE UPPER CENTER)****Torque: 80 N·m (816 kgf·cm, 59 ft·lbf)****14. INSTALL AIR CLEANER ASSEMBLY WITH HOSE (See page 10-18)****15. INSTALL V-BANK COVER SUB-ASSY****(See page 14-156)****16. ADD COOLANT (See page 16-31)****17. CHECK ENGINE COOLANT LEAK (See page 16-31)****18. INSPECT FUEL LEAK**