

<b>DTC</b>	<b>P0604</b>	<b>INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR</b>
<b>DTC</b>	<b>P0606</b>	<b>ECM/PCM PROCESSOR</b>
<b>DTC</b>	<b>P0607</b>	<b>CONTROL MODULE PERFORMANCE</b>
<b>DTC</b>	<b>P0657</b>	<b>ACTUATOR SUPPLY VOLTAGE CIRCUIT/OPEN</b>

## MONITOR DESCRIPTION

The ECM continuously monitors its internal memory status, internal circuits, and output signals to the throttle actuator. This self-check insures that the ECM is functioning properly. If any malfunction is detected, the ECM will set the appropriate DTC and illuminate the MIL.

The ECM memory status is diagnosed by internal "mirroring" of the main CPU and the sub CPU to detect random access memory (RAM) errors. The two CPUs also perform continuous mutual monitoring. The ECM sets a DTC if: 1) outputs from the 2 CPUs are different and deviate from the standards, 2) the signals to the throttle actuator deviate from the standards, 3) a malfunction is found in the throttle actuator supply voltage, and 4) any other ECM malfunction is found.

DTC No.	DTC Detection Condition	Trouble Area
P0604 P0606 P0607 P0657	ECM internal error	ECM

## MONITOR STRATEGY

Related DTCs	P0604: RAM Errors P0606: CPU Malfunction P0607: ECM CPU Malfunction P0657: ETCS Power Supply
Required sensors/ components (Main)	ECM
Required sensors/ components (Related)	–
Frequency of operation	Continuous
Duration	Within 1 second
MIL operation	Immediate
Sequence operation	None

## TYPICAL ENABLING CONDITIONS

The monitor will run whenever these DTCs are not present	See page <a href="#">05-16</a>
--	--------------------------------

## TYPICAL MALFUNCTION THRESHOLDS

### RAM Error:

RAM	RAM check failure
-----	-------------------

**CPU Malfunction:**

Either of the following conditions is met:	Condition 1 or 2
1. Difference between TPS of main CPU and TPS of sub CPU	0.3 V or more
2. Difference between APP of main CPU and APP of sub CPU	0.3 V or more

**ECM CPU Malfunction:**

Either of the following conditions is met:	Condition 1 or 2
1. All of the following conditions are met:	Condition (a), (b) and (c)
(a) CPU reset	1 time or more
(b) Difference between TP and APP learned	0.4 V or more
(c) Electronic throttle actuator	OFF
2. CPU reset	2 times or more

**ETCS Power Supply:**

ETCS power supply when more than 1 second after ignition switch OFF to ON	7 V or more
---	-------------

**INSPECTION PROCEDURE****HINT:**

Read freeze frame data using the hand-held tester or the OBD II scan tool. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.

**REPLACE ECM (See page 10-9)**