


VSC BUZZER CIRCUIT

CIRCUIT DESCRIPTION

The skid control buzzer sounds during VSC operation.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

Start inspection from step 1 in case of using the hand-held tester and start from step 2 in case of not using the hand-held tester.

1 PERFORM ACTIVE TEST BY HAND-HELD TESTER(SKID CONTROL BUZZER OPERATION)


- Select the item "VSC/BR WARN BUZ" in the ACTIVE TEST and operate the skid control buzzer on the hand-held tester.
- Check that skid control buzzer sounds "ON" and "OFF" with the hand-held tester.

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY

NG

2 INSPECT SKID CONTROL BUZZER ASSY



- (a) Disconnect the skid control buzzer connector.
- (b) Apply battery positive voltage to the terminals 1 and 2 of skid control buzzer connector, check that the skid control buzzer sounds.

NG

REPLACE SKID CONTROL BUZZER ASSY

OK

3 CHECK HARNESS AND CONNECTOR (SKID CONTROL BUZZER - SKID CONTROL ECU ASSY) ([See page 01-31](#))

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY