


REAR AXLE CARRIER SUB-ASSY LH REPLACEMENT

3006L-04

HINT:

- COMPONENTS: [See page 30-4](#)
 - Replace the RH side by the same procedures with the LH side.
1. REMOVE REAR WHEEL
 2. REMOVE STRUT ROD ASSY REAR
([See page 27-20](#))
 3. DISCONNECT REAR DISC BRAKE CALIPER ASSY LH ([See page 30-26](#))
 4. REMOVE REAR DISC
 5. DISCONNECT SKID CONTROL SENSOR WIRE
 6. REMOVE REAR AXLE HUB & BEARING ASSY LH
([See page 30-26](#))




7. DISCONNECT REAR SUSPENSION ARM ASSY NO.2 LH

- (a) Remove the bolt, nut and rear suspension arm assembly No.2 LH from the rear axle carrier sub-assy LH.

HINT:

While fixing the nut, turn and remove the bolt.




8. DISCONNECT REAR SUSPENSION ARM ASSY NO.1 LH

- (a) Remove the bolt, nut and rear suspension arm assembly No.1 LH from the rear axle carrier sub-assy LH.

HINT:

While fixing the nut, turn and remove the bolt.




9. REMOVE REAR AXLE CARRIER SUB-ASSY LH

- (a) Remove the 2 bolts, nuts and rear axle carrier sub-assy LH from the shock absorber assembly rear LH.

NOTICE:

When removing bolt, stop the bolt from rotating and loosen the nut.



10. INSTALL REAR AXLE CARRIER SUB-ASSY LH

- (a) Install the rear axle carrier sub-assy LH with the 2 bolts and nuts.


Torque: 255 N·m (2,600 kgf·cm, 188 ft·lbf)

NOTICE:

When installing bolt, stop the bolt from rotating and torque the nut.

HINT:

Insert the bolt from the rear side of the vehicle and install the nut.




11. TEMPORARY TIGHTEN REAR SUSPENSION ARM ASSY NO.1 LH

- (a) Install the rear suspension arm No. 1 to the rear axle carrier sub-assy LH with the bolt and nut, temporarily tighten the bolt.

HINT:

Insert the bolt from the front side of the vehicle and while fixing the nut, turn and install the bolt.



12. TEMPORARY TIGHTEN REAR SUSPENSION ARM ASSY NO.2 LH

- (a) Install the rear suspension arm No. 2 to the rear axle carrier sub-assy LH with the bolt and nut, temporarily tighten the bolt.

HINT:

Insert the bolt from the rear side of the vehicle and while fixing the nut, turn and install the bolt.

13. INSTALL REAR AXLE HUB & BEARING ASSY LH

(See page 30-26)

14. INSTALL SKID CONTROL SENSOR WIRE

15. INSTALL REAR DISC

16. INSTALL REAR DISC BRAKE CALIPER ASSY LH (See page 30-26)

17. TEMPORARY TIGHTEN STRUT ROD ASSY REAR

(See page 27-20)

18. STABILIZE SUSPENSION (See page 27-20)

19. FULLY TIGHTEN REAR SUSPENSION ARM ASSY NO.1 LH

(See page 27-10)

20. FULLY TIGHTEN REAR SUSPENSION ARM ASSY NO.2 LH

(See page 27-15)

21. FULLY TIGHTEN STRUT ROD ASSY REAR
([See page 27-20](#))
22. INSTALL REAR WHEEL
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
23. INSPECT AND ADJUST REAR WHEEL ALIGNMENT ([See page 27-3](#))
24. CHECK ABS SPEED SENSOR SIGNAL
w/ VSC ([See page 05-511](#))
w/o VSC ([See page 05-451](#))