

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See Page
Pressing power switch does not start system.	3. Radio receiver Assy power source circuit 4. Radio receiver Assy	05-1031
Turning on light switch does not light up night time illumination of radio receiver.	1. Radio receiver Assy LL terminal circuit 2. Radio receiver Assy	05-1033
No sound is heard from speaker in all modes.	1. Speaker circuit 2. Radio receiver Assy power source circuit 3. Radio receiver Assy	05-1035
Sound quality is bad in all modes. (Volume is too low)	1. Speaker circuit 2. Radio receiver Assy power source circuit 3. Radio receiver Assy	05-1038
Radio broadcast cannot be received. (Bad reception)	1. Antenna circuit 2. Radio receiver Assy	05-1041
Cassette tape cannot be inserted or played.	1. Cassette tape 2. Radio receiver Assy power source circuit 3. Radio receiver Assy	05-1043
Cassette tape cannot be ejected.	1. Cassette tape 2. Radio receiver Assy power source circuit 3. Radio receiver Assy	05-1045
Sound quality is bad only when playing tape.	1. Cassette tape 2. Radio receiver Assy	05-1048
Tape is tangled due to incorrect tape speed or auto-reverse mal-function.	1. Cassette tape 2. Radio receiver Assy	05-1049
CD cannot be inserted or is ejected right after insertion.	1. CD 2. Radio receiver Assy power source circuit 3. Radio receiver Assy	05-1050
Although system is powered, CD cannot be played.	1. CD 2. Radio receiver Assy power source circuit 3. Radio receiver Assy	05-1053
CD cannot be taken out.	1. CD 2. Radio receiver Assy power source circuit 3. Radio receiver Assy	05-1056
Sound quality is bad only when CD is played. (Volume is too low)	1. CD	05-1058
CD sound skips.	1. CD 2. Radio installation	05-1059
Noise occurs.	-	05-1061