

## HOW TO PROCEED WITH TROUBLESHOOTING

**1** VEHICLE BROUGHT TO WORKSHOP

**NEXT**

**2** CUSTOMER PROBLEM ANALYSIS (SEE PAGE [05-932](#))

**NEXT**

**3** CHECK AND CLEAR DTCS (SEE PAGE [05-938](#))

**NEXT**

**4** PROBLEM SYMPTOM CONFIRMATION

 SYMPTOM DOES NOT OCCUR: GO TO STEP 5

 SYMPTOM OCCURS: GO TO STEP 6

**5** SYMPTOM SIMULATION (SEE PAGE [01-32](#))

**NEXT**

**6** DTC CHECK (SEE PAGE [05-938](#))

 THERE IS NO OUTPUT: GO TO STEP 7

 THERE IS OUTPUT: GO TO STEP 8

**7** PROBLEM SYMPTOMS TABLE (SEE PAGE [05-935](#))

 CHECK FOR FLUID LEAKAGE AND GO TO STEP 10

**8** DTC CHART (SEE PAGE [05-945](#))

**NEXT**

**9** CIRCUIT INSPECTION (SEE PAGE [05-947](#) to [05-977](#))

**NEXT**

**10** IDENTIFICATION OF PROBLEM

**NEXT**

11	REPAIR
----	--------

NEXT
------

12	CONFIRMATION TEST
----	-------------------

NEXT
------

END
-----

**HINT:**

Step 3, 6, 9, and 12:

Diagnostic steps permitting the use of the hand-held tester.

Fail safe function:

When a failure occurs in the ABS system, the ABS warning light turns on and ABS operation is prohibited. In addition to this, when there is a failure which disables EBD operation, the brake warning light also turns on and EBD operation is prohibited.