

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
All doors are not operated by driver's door key cylinder interlocked with key	3. DOOR NO.2 fuse 4. ECU-IG fuse 5. Front door lock assembly LH 6. Wire harness 7. Power window master switch	05-1234
Key confinement prevention function does not work properly (Manual operation and interlocked operation with key are active)	1. Unlock warning switch assembly 2. Wire harness 3. Open door warning light (combination meter) 4. Instrument panel junction block (body ECU) 5. Front door courtesy lamp	05-1237