


## TC TERMINAL CIRCUIT

### CIRCUIT DESCRIPTION


Connecting terminals Tc and CG of the DLC3 causes the ECU to display the DTC by flashing the ABS warning light.

### WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK HARNESS AND CONNECTOR(SKID CONTROL ECU – DLC3)



- (a) Disconnect the skid control ECU connector.  
(b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
D3-13 (TC) – S1-25 (TC)	1 Ω or less

- (c) Measure the resistance according to the value(s) in the table below.


Standard:

Tester Connection	Specified Condition
D3-13 (TC) – Body ground	10 kΩ or higher

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

2 CHECK HARNESS AND CONNECTOR(DLC3 – BODY GROUND)



- (a) Disconnect the skid control ECU connector.  
(b) Measure the resistance according to the value(s) in the table below.


Standard:

Tester Connection	Specified Condition
D3-4 (CG) – Body ground	10 kΩ or higher

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

### 3 INSPECT DLC3 TERMINAL VOLTAGE(Tc TERMINAL)



- (a) Turn the ignition switch to the ON position.
- (b) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition
D3-13 (TC) – D3-4 (CG)	11 to 14 V

**NG**

**REPLACE BRAKE ACTUATOR ASSY**  
(See page [32-58](#))

**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE**  
(See page [05-883](#))