

PROBLEM SYMPTOMS TABLE

Symptom	Suspected area	See page
Engine does not start	1. Key	05-1262
	2. Transponder key amplifier	05-1262
	3. ECM	05-1262
	4. Wire harness	-