

**LIGHT AUTO TURN OFF SYSTEM LIGHT DOES NOT OPERATE****INSPECTION PROCEDURE****1 INSPECT FRONT DOOR COURTESY LAMP SWITCH ASSY**

- (a) Inspect front door courtesy lamp switch continuity.  
(1) Check that there is continuity between terminal 1 and body ground when switch is operated.

**Standard:****ON (When shaft is pressed): No continuity****OFF (When shaft is not pressed): Continuity****NG****REPLACE FRONT DOOR COURTESY LAMP SWITCH ASSY(DRIVER SIDE DOOR)****OK****2 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSY(ACC)**

- (a) Measure voltage between terminal 2A-7 (ACC) of instrument panel J/B assy and body ground.

**Standard:**

IG switch	Tester connection	Specified condition
ACC	2A-7 (ACC) - Body ground	10 - 14 V
OFF	2A-7 (ACC) - Body ground	Below 1 V

**NG****REPAIR OR REPLACE HARNESS OR CONNECTOR(POWER SOURCE)****OK****CHECK AND REPLACE INSTRUMENT PANEL JUNCTION BLOCK ASSY**