

## SEAT

## TORQUE SPECIFICATION

032HQ-01

Part Tightened	N·m	kgf·cm	ft·lbf
FRONT SEAT ASSEMBLY LH (MANUAL SEAT TYPE)			
Seat position airbag sensor x Seat adjuster	8.0	82	71 in.·lbf
Separate type front seatback cover bracket x Seat adjuster (w/ Side airbag)	5.5	56	48 in.·lbf
Front seat Inner belt assy LH x Seat adjuster	42	428	31
Front LH seat assy x Body	37	375	27
FRONT SEAT ASSEMBLY LH (POWER SEAT TYPE)			
Seat position airbag sensor x Seat adjuster	8.0	82	71 in.·lbf
Separate type front seatback cover bracket x Seat adjuster (w/ Side airbag)	5.5	56	48 in.·lbf
Front seat Inner belt assy LH x Seat adjuster	42	428	31
Front LH seat assy x Body	37	375	27