

# TERMS FOR MANUAL TRANSAXLE REPAIR MANUAL

## ABBREVIATIONS USED IN THIS MANUAL

0101A-03

Abbreviations	Meaning
E/G	Engine
FIPG	Formed In Place Gasket
MAX	Maximum
MIN	Minimum
MP	Multipurpose
M/T	Manual Transmission
N	Neutral
No.	Number
RH	Right-Hand
SPEC	Specification
SSM	Special Service Materials
SST	Special service Tools
STD	Standard
T/A	Transaxle
T/M	Transmission
TMC	TOYOTA Motor Corporation
w/	With
w/o	Without
1st	First
2nd	Second