



REPLACEMENT


1. DISCHARGE FUEL SYSTEM PRESSURE (See page 11-26)
2. REMOVE REAR SEAT CUSHION ASSEMBLY (See page 72-32)
3. REMOVE REAR FLOOR SERVICE HOLE COVER (See page 11-45)
4. SEPARATE FUEL PUMP TUBE SUB-ASSY (See page 11-45)
5. REMOVE FUEL TANK VENT TUBE SET PLATE (See page 11-45)
6. REMOVE FUEL SUCTION TUBE ASSY W/ PUMP & GAGE (See page 11-45)
7. DRAIN FUEL
8. REMOVE FLOOR PANEL BRACE REAR (See page 15-7)
9. REMOVE EXHAUST PIPE ASSY CENTER
 - (a) Remove the 2 bolts, 4 nuts, exhaust pipe and 2 gaskets.




10. DISCONNECT PARKING BRAKE CABLE ASSY NO.2
 - (a) Remove the set bolt and the set nut of the parking brake cable.



11. DISCONNECT PARKING BRAKE CABLE ASSY NO.3
 - (a) Remove the set bolt and the set nut of the parking brake cable.




12. REMOVE FUEL TANK PROTECTOR LOWER CENTER
 - (a) Remove the 4 bolts and fuel tank protector.




13. REMOVE FUEL TANK ASSY

- (a) Disconnect the fuel pump tube.
- (1) Pinch the tab of the retainer to remove the lock claws and pull down it as shown in the illustration.
 - (2) Pull out the fuel tank main tube.




NOTICE:

- Before this operation, check the connector for dirt, mud or other contamination.
- Be careful of mud. The connector's O-ring, which seals the pipe and connector, becomes contaminated easily.
- Do not use any tools in this operation.
- Do not bend or twist the nylon tube. Protect the connector by covering it with a vinyl or plastic bag.
- When the pipe and connector are stuck, push and pull the connector to release it. Then pull out the connector from the pipe.




- (b) Disconnect the fuel tube No. 1.
- (1) Pinch the tube connector and then pull out the fuel tube No. 1.




NOTICE:


- Before this operation, check the connector for dirt, mud or other contamination.
- Be careful of mud. The connector's O-ring, which seals the pipe and connector, becomes contaminated easily.
- Do not use any tools in this operation.
- Do not bend or twist the nylon tube. Protect the connector by covering it with a vinyl or plastic bag.
- When the pipe and connector are stuck, push and pull the connector to release it. Then pull out the connector from the pipe.




- (c) Set up a transmission jack underneath the fuel tank.
- (d) Remove the 2 set bolts of the fuel tank bands.
- (e) Remove the hose clamp and disconnect the fuel tank to filler pipe hose.
- (f) Disconnect the fuel tank vent hose from the charcoal canister.
 - (1) Push the connector deep into the charcoal canister to release the locking pin.
 - (2) Pinch portion A.
 - (3) Pull out the connector.
- (g) Remove the fuel tank.



- (h) Remove the 2 pins and 2 fuel tank bands as shown in the illustration.




- (i) Remove the 4 clip nuts.




14. REMOVE FUEL TANK VENT HOSE


- (a) Push the connector deep into the charcoal canister to release the locking pin.
- (b) Pinch portion A.
- (c) Pull out the connector.

**15. REMOVE FUEL PUMP TUBE SUB-ASSY**

- (a) Remove the fuel pump tube from the fuel main tube support.

**16. REMOVE FUEL MAIN TUBE SUPPORT**

- (a) Remove the bolt and tube support.

**17. REMOVE FUEL TANK CUSHION NO.2****18. INSTALL FUEL TANK CUSHION NO.2**

- (a) Install 7 new fuel tank cushions to the fuel tank.

19. INSTALL FUEL MAIN TUBE SUPPORT

Torque: 5.4 N·m (55 kgf·cm, 48 in.-lbf)

20. INSTALL FUEL PUMP TUBE SUB-ASSY**21. INSTALL FUEL TANK VENT HOSE****22. INSTALL FUEL TANK ASSY**

- (a) Install the 4 clip nuts.
 (b) Install the 2 fuel tank bands with the 2 pins.
 (c) Connect the fuel tank vent hose.
 (d) Connect the fuel tank inlet pipe with the fuel filler pipe clamp.
 (e) Tighten the set 2 bolts of the fuel tank bands.


Torque: 39 N·m (400 kgf·cm, 29 ft.-lbf)


- (f) Connect the fuel tube No. 1.

- (1) Push the fuel tube connector into the pipe until fuel tube connector makes "click" sound.

NOTICE:

- Check if there is any damage or foreign objects on the connected part.
- After connecting, check if the fuel tube connector and the pipe are securely connected by trying to pull them apart.





- (g) Connect the fuel pump tube.
 (1) Push in the fuel tube connector to the pipe until, and push up retainer to the claws lock.

NOTICE:

- Check if there is any damage or foreign objects on the connected part.
- After connecting, check if the fuel tube connector and the pipe are securely connected by trying to pull them apart.

23. INSTALL FUEL TANK PROTECTOR LOWER CENTER

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

24. INSTALL PARKING BRAKE CABLE ASSY NO.3

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

25. INSTALL PARKING BRAKE CABLE ASSY NO.2

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

26. INSTALL EXHAUST PIPE ASSY CENTER

- (a) Install 2 new gaskets and the exhaust pipe with the 2 bolts and 4 new nuts.

Torque: 56 N·m (571 kgf·cm, 41 ft·lbf)

27. INSTALL FUEL SUCTION TUBE ASSY W/ PUMP & GAGE (See page 11-45)**28. INSTALL FUEL TANK VENT TUBE SET PLATE (See page 11-45)****29. CONNECT FUEL PUMP TUBE SUB-ASSY (See page 11-45)****30. ADD FUEL****31. CHECK FOR FUEL LEAKS (See page 11-29)****32. CHECK FOR EXHAUST GAS LEAKS****33. INSTALL REAR FLOOR SERVICE HOLE COVER (See page 11-45)****34. INSTALL REAR SEAT CUSHION ASSEMBLY (See page 72-32)****35. INSTALL FLOOR PANEL BRACE REAR (See page 15-7)**