


INSPECTION



1. LHD and RHD driver's seat:

INSPECT FRONT SEAT INNER BELT ASSY


- (a) When fastening the seat belt (Buckle switch is ON).

- (1) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
1 ⇔ 4 (1 ⇔ 6)* ¹	330Ω (Continuity)

If the result is not as specified, replace the front seat inner belt assembly.



- (b) When releasing the seat belt (Buckle switch is OFF).


- (1) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
1 ⇔ 4 (1 ⇔ 6)* ¹	1330Ω (No continuity)

*¹ Only for RHD models.

If the result is not as specified, replace the front seat inner belt assembly.



2. LHD and RHD passenger's seat:

INSPECT FRONT SEAT INNER BELT ASSY

- (a) Short between connector terminals 1 and 3 of the occupation sensor.


- (b) When fastening the seat belt (Buckle switch is ON).


- (1) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
1 ⇔ 4	Continuity
1 ⇔ 3	No continuity

If the result is not as specified, replace the front seat inner belt assembly.






- (c) When releasing the seat belt (Buckle switch is OFF).
- (1) Inspect the continuity and resistance between the terminals.


Standard:

Terminal No.	Specified condition
1 ⇔ 4	No continuity
1 ⇔ 3	Continuity

If the result is not as specified, replace the front seat inner belt assembly.



- (d) Release the occupation sensor connector.




- (e) When fastening the seat belt (Buckle switch is ON).

- (1) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
1 ⇔ 4	Continuity
1 ⇔ 3	No continuity

If the result is not as specified, replace the front seat inner belt assembly.



- (f) When releasing the seat belt (Buckle switch is OFF).

- (1) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
1 ⇔ 4	No continuity
1 ⇔ 3	Continuity

If the result is not as specified, replace the front seat inner belt assembly.