

## SFI SYSTEM (2AZ-FE)

### ON-VEHICLE INSPECTION

10068-06

#### 1. CHECK THROTTLE BODY

- (a) Listen to the throttle control motor operating sounds.
  - (1) Turn the ignition switch ON.
  - (2) When pressing the accelerator pedal position sensor lever, listen to the running motor. Make sure no friction noise comes from the motor.

If friction noise exists, replace the throttle body.

- (b) Check the throttle position sensor.
  - (1) Connect the hand-held tester or OBD II scan tool to the DLC3.
  - (2) Turn the ignition switch ON.
  - (3) Check that the check engine warning light does not light up.
  - (4) Under CURRENT DATA, the throttle valve opening percentage (THROTTLE POS) should be within the standard value range below.

**Standard throttle valve opening percentage: 60% or more**

If the percentage is less than 60%, replace the throttle body.

#### NOTICE:

**When checking the standard throttle valve opening percentage, the transmission should be in the neutral position.**

#### 2. CHECK ACCELERATOR PEDAL POSITION SENSOR

- (a) Turn the ignition switch ON. Under CURRENT DATA, the voltage of the throttle position sensor should be within the standard value range below.

**Standard: 0.6 to 1.0 V**

If the result is not as specified, replace the accelerator pedal position sensor.


#### 3. CHECK CAMSHAFT TIMING OIL CONTROL VALVE ASSY

- (a) Connect the hand-held tester or OBD II scan tool to the DLC3.
- (b) Turn the ignition switch ON.
- (c) Start the engine and warmed it up.
- (d) Select the VVT from the ACTIVE TEST menu.
- (e) Check the engine speed when the OCV is operated by the hand-held tester.

**Standard:**

| Condition                      | Specified Condition          |
|--------------------------------|------------------------------|
| VVT system is OFF (OCV is OFF) | Normal engine speed          |
| VVT system is ON (OCV is ON)   | Rough idle or engine stalled |

If the result is not as specified, replace the OCV assy.




#### 4. CHECK MASS AIR FLOW METER (MAF meter)

##### NOTICE:

- Perform the MAF meter inspection by following the procedures below.
- Only replace the MAF meter when both the LONG FT#1 value and MAF value in the DATA LIST (with the engine stopped) are not within the normal operating range.

- (a) Perform confirmation driving pattern.
- (1) Connect the hand-held tester to the DLC3.
  - (2) Turn the ignition switch ON.
  - (3) Turn the tester on.
  - (4) Clear the DTCs (see page 05-41).
  - (5) Start the engine and warm it up with all accessory switches off (until the engine coolant temperature is 75°C (167°F) or more).
  - (6) Drive the vehicle at 31 mph (50 km/h) or more for 3 to 5 minutes. \*1
  - (7) Allow the engine to idle for 2 minutes. \*2
  - (8) Perform steps \*1 and \*2 at least 3 times.



- (b) Read value using the hand-held tester (LONG FT#1).
- (1) Select the following menu items: DIAGNOSIS / ENHANCED OBD II / DATA LIST / PRIMARY / LONG FT#1.
  - (2) Read the values displayed on the tester.

**Standard value:**

**Within -15 to +15 %**

If the result is not within the specified range, perform the inspection below.

- (c) Read value using the hand-held tester (MAF).

**NOTICE:**

- **Turn off the engine.**
  - **Perform the inspection with the vehicle indoors and on a level surface.**
  - **Perform the inspection of the MAF meter while it is installed to the air cleaner case (installed to the vehicle).**
  - **During the test, do not use the exhaust air duct to perform suction on the exhaust pipe.**
- (1) Turn off the engine (do not run the engine).
  - (2) Turn the ignition switch ON.
  - (3) Turn the tester on.
  - (4) Select the following menu items: DIAGNOSIS / ENHANCED OBD II / DATA LIST / PRIMARY / PRIMARY / MAF.
  - (5) Wait 30 seconds, and read the values on the hand-held tester.

**Standard condition:**

**Less than 0.54 g/s**

- If the result is not as specified, replace the MAF meter.
- If the result is within the specified range, inspect the cause of the extremely rich or lean air fuel ratio (see page 05-138).