


<b>DTC</b>	<b>C1241/41</b>	<b>LOW BATTERY POSITIVE VOLTAGE OR ABNORMALLY HIGH BATTERY POSITIVE VOLTAGE</b>
------------	-----------------	---

## CIRCUIT DESCRIPTION


DTC No.	DTC Detecting Condition	Trouble Area
C1241/41	Detection of any of conditions 1. or 2.: 1. Vehicle speed is at 3 km/h (1.9 mph) or higher and voltage of ECU terminal IG1 remains at below 9.5 V for more than 10 sec. 2. The condition that ECU terminal IG1 voltage is more than 17.0 V continues for 1.2 sec. or more.	<ul style="list-style-type: none"> <li>• Battery</li> <li>• IC regulator</li> <li>• Power source circuit</li> </ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 INSPECT FUSE(ECU-IG OF DRIVER SIDE J/B)



- (a) Remove ECU-IG fuse from the driver side J/B.
- (b) Check continuity of ECU-IG fuse.

**OK: Continuity**

**NG**

**INSPECT FOR SHORT CIRCUIT IN ALL HARNESS AND COMPONENTS CONNECTED TO ECU-IG FUSE**

**OK**

### 2 INSPECT BATTERY(TERMINAL VOLTAGE)

- (a) Check the battery positive voltage.

**OK: 10 - 14 V**

**NG**

**CHECK CHARGING SYSTEM**


**OK**

### 3 CHECK VOLTAGE OF ECU IG POWER SOURCE

#### IN CASE OF USING THE HAND-HELD TESTER:

- (a) Select the DATALIST mode on the hand-held tester.
- (b) Check the voltage condition output from the ECU displayed on the hand-held tester.

**OK: "Normal" is displayed.**



#### IN CASE OF NO USING THE HAND-HELD TESTER:

- (a) Remove the skid control ECU with connectors still connected.
- (b) Turn the ignition switch ON, measure voltage between terminals IG1 and GND of skid control ECU connector.

**OK: 10 - 14 V**

**OK**

**CHECK AND REPLACE SKID CONTROL ECU ASSY**

**NG**

4	CHECK CONTINUITY(SKID CONTROL ECU ASSY - BODY GROUND)
---	---

NG	REPAIR OR REPLACE HARNESS OR CONNECTOR
----	--

OK
----

CHECK AND REPAIR HARNESS AND CONNECTOR
--