

## PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

### NOTICE:

**When replacing the skid control ECU, sensor, etc., turn the ignition switch to OFF.**

Symptom	Suspected Area	See page
ABS does not operate	<ol style="list-style-type: none"> <li>1. Check the DTC reconfirming that the normal code is output.</li> <li>2. IG power source circuit</li> <li>3. Speed sensor circuit</li> <li>4. Check the brake actuator with the hand-held tester. If there is a malfunction, check the hydraulic circuit for leakage.</li> <li>5. When the above areas (1. to 4.) are all normal but the problem still occurs, replace the skid control ECU.</li> </ol>	<a href="#">05–873</a>  <a href="#">05–906</a> <a href="#">05–884</a> <a href="#">05–890</a>
ABS does not operate properly	<ol style="list-style-type: none"> <li>1. Check the DTC reconfirming that the normal code is output.</li> <li>2. Speed sensor circuit</li> <li>3. Stop light switch circuit</li> <li>4. Check the brake actuator with the hand-held tester. If there is a malfunction, check the hydraulic circuit for leakage.</li> <li>5. When the above areas (1. to 4.) are all normal but the problem still occurs, replace the skid control ECU.</li> </ol>	<a href="#">05–873</a>  <a href="#">05–884</a> <a href="#">05–890</a> <a href="#">05–910</a> <a href="#">32–57</a>
ABS warning light malfunction (Remains ON)	<ol style="list-style-type: none"> <li>1. ABS warning light circuit</li> <li>2. Skid control ECU</li> </ol>	<a href="#">05–917</a> –
ABS warning light malfunction (Does not light up)	<ol style="list-style-type: none"> <li>1. ABS warning light circuit</li> <li>2. Skid control ECU</li> </ol>	<a href="#">05–920</a> –
DTC check cannot be performed	<ol style="list-style-type: none"> <li>1. ABS warning light circuit</li> <li>2. Tc terminal circuit</li> <li>3. When the above areas (1. and 2.) are all normal but the problem still occurs, replace the skid control ECU.</li> </ol>	<a href="#">05–917</a> <a href="#">05–920</a> <a href="#">05–925</a>
Speed sensor signal check cannot be performed	<ol style="list-style-type: none"> <li>1. Harness and/or connector between skid control ECU and DLC3.</li> <li>2. Skid control ECU</li> </ol>	– –