

PROBLEM SYMPTOMS TABLE

If there are no DTCs output but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing the skid control ECU, sensor, etc., turn the ignition switch off.

Symptoms	Suspected Areas	See page
ABS does not operate BA does not operate EBD does not operate	1. Check the DTC again and make sure that the normal code is output 2. IG power source circuit and ground circuit 3. Speed sensor circuit 4. Check the brake actuator with a hand-held tester If abnormal, check the hydraulic circuit for leakage 5. If the symptoms still occur even after the above circuits in suspected areas are inspected and proved to be normal, replace the skid control ECU	05-1002 05-1055 05-1013 05-1019 32-62
ABS does not operate efficiently BA does not operate efficiently EBD does not operate efficiently	1. Check the DTC again and make sure that the normal code is output 2. Speed sensor circuit 3. Stop lamp switch circuit 4. Check the brake actuator with a hand-held tester If abnormal, check the hydraulic circuit for leakage 5. If the symptoms still occur even after the above circuits in suspected areas are inspected and proved to be normal, replace the skid control ECU	05-1002 05-1013 05-1019 05-1060 32-62
ABS warning light (Remains ON)	1. ABS warning light circuit 2. Skid control ECU	05-1066 –
ABS warning light (Does not light up)	1. ABS warning light circuit 2. Skid control ECU	05-1070 –
DTC check of ABS cannot be done	1. Check the DTC again and make sure that the normal code is output 2. Tc terminal circuit 3. If the symptoms still occur even after the above circuits in suspected areas are inspected and proved to be normal, replace the skid control ECU	05-1002 05-1095
Sensor signal check cannot be done	1. Ts terminal circuit 2. Skid control ECU	05-1101 –
VSC and/or TRAC does not operate	1. Check the DTC again and make sure that the normal code is output 2. IG power source circuit and ground circuit 3. Check the hydraulic circuit for leakage 4. Speed sensor circuit 5. Deceleration sensor circuit 6. Yaw rate sensor circuit 7. Steering sensor circuit 8. If the symptoms still occur even after the above circuits in suspected areas are inspected and proved to be normal, replace the skid control ECU	05-1002 05-1055 – 05-1013 05-1019 05-1052 05-1052 05-1049
SLIP indicator light abnormal	1. SLIP indicator light circuit 2. Skid control ECU	05-1089 –

Symptoms	Suspected Areas	See page
TRAC OFF indicator abnormal	<ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output 2. TRAC control switch circuit 3. If the symptoms still occur even after the above circuits in suspected areas are inspected and proved to be normal, replace the skid control ECU 	05-1002 05-1085
DTC check of VSC cannot be done	<ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output 2. Tc terminal circuit 3. If the symptoms still occur even after the above circuits in suspected areas are inspected and proved to be normal, replace the skid control ECU 	05-1002 05-1095
VSC warning light (Remains ON)	<ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output 2. VSC warning circuit 3. If the symptoms still occur even after the above circuits in suspected areas are inspected and proved to be normal, replace the skid control ECU 	05-1002 05-1073
VSC warning light (Does not light up)	<ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output 2. VSC warning circuit 3. If the symptoms still occur even after the above circuits in suspected areas are inspected and proved to be normal, replace the skid control ECU 	05-1002 05-1076