

ABS WITH EBD & BA & TRAC & VSC SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

0567S-01

1 Vehicle Brought to Workshop

2 Customer Problem Analysis (See page 05-509)

3 Check and Clear DTCs and Freeze Frame Data (See page 05-511)

4 Problem Symptom Confirmation

Symptom does not occur: Go to step 5

Symptom occur: Go to step 6

5 Symptom Simulation (See page 01-21)

6 DTC Check (See page 05-511)

There is no output: Go to step 7

There is output: Go to step 8

7 Problem Symptoms Table (See page 05-531)

Check for fluid leakage and Go to step 10

8 DTC Chart (See page 05-523)

9 Circuit Inspection (See page)

10 Identification of Problem

11	Repair
----	--------



12	Confirmation Test
----	-------------------



End

HINT:

Step 3, 6, 9, 12:

Diagnostic steps permitting the use of the hand-held tester.

Fail safe function:

When a failure occurs in the ABS & TRC & VSC & EBD system, the ABS and VSC warning light turns on and the ABS & TRC & VSC & EBD operation is prohibited. In addition to this, when there is a failure which disables the EBD operation occurs, the brake warning light also turns on and the EBD operation is prohibited.