

# COMBINATION METER

## PROBLEM SYMPTOMS TABLE

7105W-01

### Warning Lights and Buzzer:

Symptom	Suspect Area	See page
Check Engine warning light does not light up.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	– <a href="#">05-1</a> –
Discharge warning light does not light up.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	– <a href="#">05-1</a> –
Brake warning light does not light up.	1. Wire Harness or Connector 2. Skid control ECU 3. Combination Meter Assy	– <a href="#">05-448</a> –
ABS warning light does not light up.	1. Wire Harness or Connector 2. Skid control ECU 3. Skid control ECU with Actuator 4. Combination Meter Assy	– <a href="#">05-448</a> <a href="#">05-507</a> –
SRS warning light does not light up.	1. Wire Harness or Connector 2. Airbag Sensor Assy 3. Combination Meter Assy	– <a href="#">05-770</a> –
Open Door warning light does not light up.	1. Wire Harness or Connector 2. Front Door Courtesy Light 3. MPX Body ECU 4. Combination Meter Assy	– <a href="#">05-981</a> – –
Fuel Level warning light does not light up.	1. Wire Harness or Connector 2. Fuel Level Warning Switch 3. Combination Meter Assy	– – –
Low Oil Pressure warning light does not light up.	1. Wire Harness or Connector 2. Low Oil Pressure Warning Switch 3. Combination Meter Assy	– – –
Window washer level warning does not lights up	1. Wire Harness or Connector 2. Window washer level waring switch 3. Combination Meter Assy	– – –

### Indicator Lights:

Symptom	Suspect Area	See page
Shift indicator lights do not light up.	1. Wire Harness or Connector 2. Neutral Start Switch Circuit 3. Combination Meter Assy	– <a href="#">05-637</a> –
Turn indicator light does not light up.	1. Wire Harness or Connector 2. Turn Signal and Hazard Warning System 3. Combination Meter Assy	– <a href="#">05-981</a> –
High Beam indicator light does not light up.	1. Wire Harness or Connector 2. Headlight Dimmer Switch 3. Combination Meter Assy	– <a href="#">05-981</a> –
O/D OFF indicator light does not light up.	1. Wire Harness or Connector 2. O/D Main Switch Circuit 3. ECM 4. Combination Meter Assy	– <a href="#">05-611</a> <a href="#">05-1</a> –
TRC indicator light does not light up.	1. Wire Harness or Connector 2. VSC OFF Indicator, VSC Cut Switch Circuit 3. Combination Meter Assy	– <a href="#">05-531</a> –
SLIP indicator light does not light up.	1. Wire Harness or Connector 2. Slip Indicator Circuit 3. Combination Meter Assy	– <a href="#">05-531</a> –

**Meter Gauges:**

Symptom	Suspect Area	See page
Tachometer, Fuel Gauge and Water Temperature Gauge do not operate.	1. Wire Harness or Connector	-
	2. GAUGE Fuse	-
	3. Combination Meter Assy	-
Fuel Gauge does not operate or abnormal operation.	1. Wire Harness or Connector	-
	2. Fuel Receiver Gauge	-
	3. Combination Meter Assy	-