

INNER REAR VIEW MIRROR ASSY REPLACEMENT

700LA-01

HINT:

The installation is in the reverse order of the removal.

1. REMOVE INNER REAR VIEW MIRROR ASSY

- (a) Remove the screw.
- (b) w/ Erector chromic inner mirror:
Remove the inner rear view mirror cover.
- (c) w/ Erector chromic inner mirror:
Disconnect the connector.
- (d) Remove the rear view inner mirror assembly.