

## PROBLEM SYMPTOMS TABLE

Problem Symptom	Suspected Area	See Page
All doors are not operated by the driver's door key cylinder interlocked with key	<ol style="list-style-type: none"><li>1. DOOR NO.2 fuse</li><li>2. ECU-IG fuse</li><li>3. Front door lock assy LH</li><li>4. Wire harness</li><li>5. Power window regulator master switch</li></ol>	<a href="#">05-2081</a>
Key lock-in prevention function does not work properly (Manual operation and interlocked operation with key are active)	<ol style="list-style-type: none"><li>1. Unlock warning switch assy</li><li>2. Wire harness</li><li>3. Open door warning light (Combination meter)</li><li>4. Instrument panel junction block (body ECU)</li><li>5. Front door courtesy lamp</li></ol>	<a href="#">05-2085</a>