

PROBLEM SYMPTOMS TABLE

Problem Symptom	Suspected Area	See Page
Power window does not operate (ALL) (Power Door Lock does not operate)	1. Power No.1 fuse (Instrument panel J/B) 2. Power main relay (Instrument panel J/B) 3. Wire harness	68-1 70-2 –
Power window does not operate (ALL) (Power Door Lock is normal)	1. Ignition switch assy 2. Power window regulator master switch 3. Wire harness 4. Power window regulator motor	80-2 05-2058 – 70-2
"One-Touch Power Window System" does not operate	1. Power window regulator master switch 2. Power window regulator motor (drivers side)	05-2060 70-2
Only one window glass does not move.	1. Power window regulator master switch 2. Power window switch 3. Power window motor 4. Wire harness	70-2 70-2 70-2 –
"Window Lock System" does not operate	1. Power window regulator master switch 2. Wire harness	70-2 –