

## Service Hints

### TAIL Relay

5-3 : Closed with the light control SW at TAIL or HEAD position

### C11 Combination SW

14-16 : Closed with the light control SW at TAIL or HEAD position

## ○ : Parts Location

Code		See Page	Code	See Page	Code	See Page
B5	A	40 (LHD)	F2	36 (LHD 1MZ–FE)	L1	43 (LHD)
C11		40 (LHD)		38 (*1)	L2	43 (LHD)
F1		36 (LHD 1MZ–FE)	J4	41 (LHD)	R13	43 (LHD)
		38 (*1)	J11	42 (LHD)	R14	43 (LHD)

\* 1 : LHD 2AZ-FE, 1AZ-FE

## ○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2E	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2G		
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)

## ▽ : Ground Points

Code	See Page	Ground Points Location
EB	56 (LHD 1MZ-FE)	Right Fender
	58 (*1)	
EC	56 (LHD 1MZ-FE)	Left Fender
	58 (*1)	
IK	60 (LHD)	Instrument Panel Brace LH
BQ	64 (LHD)	Front Side of Rear Quarter Wheel House LH
BS	64 (LHD)	Lower Back Panel Center

\* 1 : LHD 2AZ-FE, 1AZ-FE

## ○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I9	62 (LHD)	Floor Wire	B8	64 (LHD)	Floor Wire
B7	64 (LHD)		B9		